

RADview-EMS

Element Management System

ASMi-52

Contents

Chapter 1. Introduction

1.1	Overview of the RADview FCAPS Model	1-1
1.2	Overview of the ASMi-52 Device.....	1-1
	Using the Graphical User Interface	1-2
	LEDs.....	1-3
	Port Status	1-5
1.3	System Level Operations.....	1-5
1.4	Modem Level Operations	1-6
1.5	SHDSL Link Port Level Operations.....	1-8
1.6	ETH Port Level Operations	1-9
1.7	E1 and T1 Port Level Operations	1-9
1.8	DTE (V.35, X.21, RS-530) Port Levels Operations.....	1-10
1.9	CONTROL Port Level Operations	1-11
1.10	Repeater Level Operations.....	1-11

Chapter 2. Fault Management

2.1	System Level – Fault Menu	2-1
	Masking the Alarms.....	2-1
	Clearing the History Log.....	2-1
2.2	Modem Level – Fault Menu	2-2
	Displaying the Active Alarms for Modems and Ports	2-2
	Displaying the Active Alarms at the Modem Level	2-3
	Displaying the History Log	2-5
2.3	SHDSL Link Port Level – Fault Menu	2-6
	Displaying the Active Alarms at the SHDSL Link Port Level	2-6
2.4	ETH Port Level – Fault Menu	2-8
	Displaying the Active Alarms at the ETH Port Level.....	2-8
2.5	E1 and T1 Port Levels – Fault Menu.....	2-9
	Displaying the Active Alarms at the E1 Port Level.....	2-9
2.6	DTE (V.35, X.21, RS-530, IR-IP) Port Levels – Fault Menu	2-11
	Displaying the Active Alarms at the DTE (V.35, X.21, RS-530, IR-IP) Port Levels.....	2-11
2.7	Repeater Level – Fault Menu	2-12
	Displaying the Active Alarms at the Repeater Level.....	2-12
	Displaying the History Log	2-14

Chapter 3. Configuration Management

3.1	System Level – Configuration Menu	3-1
	Viewing and Setting System Information.....	3-1
	Polling the Agent.....	3-2
3.2	System Level – Options Menu	3-2
	Viewing the Host Interface List.....	3-3
	Configuring the Manager List.....	3-5
	Setting the Polling Option	3-6
3.3	Modem Level – Configuration Menu	3-6
	Viewing Modem Information	3-6

Configuring the Modem Parameters	3-7
Viewing Available Bandwidth	3-8
Defining the Time Slot Assignment	3-10
Configuring the LAN	3-13
Configuring the Bridging Table	3-14
Configuring QoS Mapping.....	3-17
Resetting the Configuration	3-18
3.4 Modem Level – Diagnostics Menu	3-18
Testing the Modem Diagnostics.....	3-18
Configuring BERT Testing.....	3-20
3.5 SHDSL Link Port Level – Configuration Menu	3-21
Configuring the SHDSL Link Port Parameters.....	3-21
Viewing the SHDSL Link Port Status Configuration	3-23
3.6 Ethernet Port Level – Configuration Menu	3-25
Configuring the ETH Port Parameters	3-25
3.7 E1 and T1 Port Levels – Configuration Menu	3-26
Configuring the Parameters for the E1 Port.....	3-26
Configuring the Parameters for the T1 Port.....	3-29
3.8 DTE (V.35, RS-530) Port Level – Configuration Menu	3-30
Configuring the DTE (V.35, RS-530) Port Parameters	3-30
3.9 CONTROL Port Level – Configuration Menu	3-31
Configuring the CONTROL Port Parameters.....	3-32
3.10 Repeater Level – Configuration Menu	3-33
Configuring the Repeater Parameters	3-34
Resetting the Repeater Network Side	3-35
3.11 Repeater Level – Diagnostics Menu	3-35
Testing the Repeater Diagnostics.....	3-35

Chapter 4. Performance Monitoring

4.1 System Level – Statistics Menu	4-1
Setting the Polling Interval.....	4-1
4.2 Modem Level – Statistics Menu.....	4-2
Clearing Modem Statistics	4-2
4.3 SHDSL Link Port Level – Statistics Menu	4-2
Viewing Current 15-Minute Data for the SHDSL Link Port.....	4-2
Viewing One-Day Current Data for the SHDSL Link Port.....	4-4
Viewing 15-Minute Interval Data for the SHDSL Link Port.....	4-6
Viewing One-Day Interval Data for the SHDSL Link Port.....	4-8
Viewing Accumulated Data for the SHDSL Link Port	4-10
Clearing Statistics for the SHDSL Link Port.....	4-11
4.4 E1/T1 Port Level – Statistics Menu.....	4-11
Viewing BPV Statistics	4-12
Viewing Current 15-Minute Port Data	4-13
Viewing 15-Minute Interval Port Data	4-15
Clearing Statistics for the E1/T1 Port	4-17

Appendix A. Active Alarms

Chapter 1

Introduction

This chapter provides an overview of the ASMi-52 device and the RADview ASMi-52 user interface.

1.1 Overview of the RADview FCAPS Model

RADview provides a complete management solution for monitoring and controlling the ASMi-52 device. The RADview solutions conform to ITU-T Telecommunication Management Network (TMN) recommendations for SNMP management systems, known as the FCAPS model:

- **Fault management** – detects and correlates fault in network devices, isolates faults, and initiates recovery actions
- **Configuration management** – tracks configuration changes and configures, installs, and distributes software and configuration files across the network
- **Performance management** – continuously monitors network performance (QoS, CoS) and resource allocation

1.2 Overview of the ASMi-52 Device

ASMi-52 is a part of SHDSL technology, which offers a cost-effective solution for delivering digital data. The data is delivered to customer premises over the existing copper cables of the distribution network, while eliminating the need for repeaters. The ASMi-52 modem is based on multiple-line rate SHDSL technology. The modem is fully synchronous and operates in full duplex form. The modem uses 2-wire or 4-wire line pairs, or a single unconditional copper twisted pair. The ASMi-52 modem can operate as a CO or CPE unit (according to method of use and user configuration). Different units are not required. The ASMi-52 unit can be configured locally via a 10/100 mbps Ethernet port (as an ordering option) or via an RS-232 control port. ASMi-52, together with an E1 interface port support, can also access the modem via a dedicated time slot in the E1 interface.

Using the Graphical User Interface




Figure 1-1. RADview ASMi-52 Window

Note In the above figure, one repeater is displayed. However, the ASMi-52 device may include up to eight repeaters.

The RADview graphical user interface provides a dynamically updated graphical representation of the Near End ASMi-52, the Far End modem, and the repeaters that exist between them. ASMi-52 devices are displayed with their front and rear panels, allowing you to monitor and manage their operations. The window includes port interfaces and their operational and communication statuses, as well as the devices' LED indicator statuses. Configuration and monitoring can be done at the system level, modem level, and port level.

Selecting Objects in the Window

You can select any of the following objects in the window:

- System (entire window) – Click the light blue frame surrounding the window.
- Modem (Far End or Near End) – Click the light blue frame surrounding the desired device.
- Port [SHDSL link, ETH, E1/T1, DTE (V.35/X.21/RS-530), CONTROL] – Click the light blue frame surrounding the desired port.
- Repeater(s)

Displaying Near End and Far End Modems

The Near End (NE) device, the ASMi-52, is displayed with its front and back panel, LEDs, and ports.

The Far End (FE) device is fully displayed as well if it is an ASMi-52/Master/Slave device. Otherwise, an empty box is displayed with the FE modem name on it.

Whether the Far End is displayed depends on its modem type. [Table 1-1](#) displays the available Far End display options.

Table 1-1. Far End Display Options

FE Modem	Modem Type	Managed/Unmanaged
Unknown	Unknown	Unmanaged
ASMi-52	ASMi-52 SA	Managed
ASMi-52 Master	ASMi-52 SA	Managed
ASMi-52 Slave	ASMi-52 SA	Managed
ASMi-52/CD	LRS-24 Card	Managed
ASMi-52/CQ	LRS-24 Card	Managed
LRS-52	LRS-52	Managed
D8SL	DXC Card	Managed
MP-SHDSL	MP Card	Managed
FCD-IP	FCD-IP	Unmanaged
FCD-IPM	FCD-IPM	Unmanaged

Menu Bar

The menu bar includes the following pull-down menus: Configuration, Fault, Diagnostics, Options, and Help. Menu availability and content varies depending on the selected object (system, modem, or port).

Toolbar

The following buttons are available on the toolbar:



System Info – Displays the system information for the selected interface



Poll Agent – Polls the Agent immediately

Status Bar

The status bar indicates if RADview ASMi-52 is ready, if there is a system error, or if the Agent is currently being polled.

LEDs

Note LED status is displayed only for ASMi-52 and ASMi-52 Master/Slave devices.

The front panel of ASMi-52 includes a series of LED indicators that show the current operating status. [Table 1-2](#) lists and describes the ASMi-52 LED indicators.

Table 1-2. ASMi-52 LEDs

Name	Function	Location
PWR (green)	ON – Power supply is ON OFF – Power supply is OFF	Front panel
TST (red)	ON – Test is active on one of the device's ports OFF – No test is active on any of the device's ports	Front panel

Table 1-2. ASMi-52 LEDs (Cont.)

Name	Function	Location
SYNC (green/red) or SYNC A (green/red)	<p>The SYNC LED is for 2W modems</p> <p>The SYNC A LED is for 4W modems</p> <ul style="list-style-type: none"> ON (red) – Ssync Line A operation state is IDLE, BOOTUP_LOAD, or BOOTUP_LOAD_DONE Blinking (red) – Ssync Line A operation state is HANDSHAKE_OP Blinking (green) – TRAINING_OP and FRAMER_SYNC ON (green) – Ssync Line A operation state is DATA 	Front panel
SYNC B (green/red)	<p>The SYNC B LED is only applicable for 4W modems</p> <ul style="list-style-type: none"> ON (red) – Ssync Line B operation state is IDLE, BOOTUP_LOAD, or BOOTUP_LOAD_DONE Blinking (red) – Ssync Line B operation state is HANDSHAKE_OP Blinking (green) – TRAINING_OP and FRAMER_SYNC ON (green) – Ssync Line B operation state is DATA 	Front panel
AIS (yellow) or YELLOW (yellow)	<p>The AIS LED is applicable only for the E1 interface</p> <ul style="list-style-type: none"> ON – AIS received OFF – No AIS received <p>The YELLOW LED is applicable only for the T1 interface</p> <ul style="list-style-type: none"> ON – Yellow alarm OFF – No Yellow alarm 	Front panel
E1 SYNC / T1 SYNC (red) or DATA (yellow)	<p>The E1 SYNC / T1 SYNC LED is only applicable for an E1/T1 interface</p> <ul style="list-style-type: none"> ON (red) – E1/T1 is not synchronized OFF – E1/T1 is synchronized <p>The DATA LED is not applicable for an E1/T1 interface</p> <p>Blinking (yellow) – Data is being received or transmitted via the DTE interface</p> <p>OFF – No data</p>	Front panel
ALM (red)	<p>ON (red) – An alarm exists</p> <p>OFF – No data</p>	Front panel

Port Status

The operational status of each physical port is indicated by the color of the port. The color displayed is based both on polling and on notifications of interface operational status.

The color appears according to the following order of conditions:

Table 1-3. ASMi-52 Port Statuses

Name	Function	Location
Magenta	There are failures on the port	Front panel
Light Blue	There is an active test on the port	Front panel
Gray	The port is operational, and no test is running	Front panel

1.3 System Level Operations

Table 1-4 lists the different management options for the system level.

Table 1-4. System Management Options

Tasks – Fault	Dialog Box and/or Parameter Location	Path
Masking the alarms	Refer to Masking the Alarms in Chapter 2 .	Fault ➤Mask Alarms...
Clearing the history log	Refer to Clearing the History Log in Chapter 2 .	Fault ➤History Log ➤Clear All
Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Configuring system information	System Information Dialog Box Refer to Viewing and Setting System Information in Chapter 3 .	Configuration ➤System Info...
Polling the Agent	Refer to Polling the Agent in Chapter 3 .	Configuration ➤Poll Agent
Viewing the host interface list	Host Interface List Dialog Box Refer to Viewing the Host Interface List in Chapter 3 .	Options ➤Host Interface List...
Configuring the manager list	Manager List Dialog Box Refer to Configuring the Manager List in Chapter 3 .	Options ➤Manager List...
Setting the polling option	Refer to Setting the Polling Option in Chapter 3 .	Options ➤Polling

Table 1-4. System Management Options (Cont.)

Task – Statistics	Dialog Box and/or Parameter Location	Path
Setting the polling interval	<i>Polling Interval Dialog Box</i> Refer to <i>Setting the Polling Interval</i> in <i>Chapter 4</i> .	Statistics ➤Polling Interval...

1.4 Modem Level Operations

Table 1-5 lists the different management options for the modem level.

Table 1-5. Modem Management Options

Tasks – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms for modems and ports	<i>All Modem Active Alarm List Dialog Box</i> Refer to <i>Displaying the Active Alarms for Modems and Ports</i> in <i>Chapter 2</i> .	Fault ➤Active Alarms ➤Modem & Ports...
Displaying the active alarms at the modem level	<i>Modem Active Alarm List Dialog Box</i> Refer to <i>Displaying the Active Alarms at the Modem Level</i> in <i>Chapter 2</i> .	Fault ➤Active Alarms ➤Modem Level...
Displaying the history log for the active alarms at the modem level	<i>Modem Alarm Buffer List Dialog Box</i> Refer to <i>Displaying the History Log</i> in <i>Chapter 2</i> .	Fault ➤History Log ➤List...
Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Viewing modem information	<i>Modem Information Dialog Box</i> Refer to <i>Viewing Modem Information</i> in <i>Chapter 3</i> .	Configuration ➤Modem Info...
Configuring the modem parameters	<i>Modem Parameters Dialog Box</i> Refer to <i>Configuring the Modem Parameters</i> in <i>Chapter 3</i> .	Configuration ➤Modem Parameters...
Viewing available bandwidth	<i>Bandwidth Allocation Dialog Box</i> Refer to <i>Viewing Available Bandwidth</i> in <i>Chapter 3</i> .	Configuration ➤Bandwidth Allocation...

Table 1-5. Modem Management Options (Cont.)

Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the LAN	<i>LAN Configuration Dialog Box</i> Refer to <i>Configuring the LAN in Chapter 3</i> .	Configuration ➤ LAN Configuration...
Configuring the bridging table	<i>Bridging Table Dialog Box</i> Refer to <i>Configuring the Bridging Table in Chapter 3</i> .	Configuration ➤ Bridging Table...
Configuring QoS mapping	<i>QoS Mapping Dialog Box</i> Refer to <i>Configuring QoS Mapping in Chapter 3</i> .	Configuration ➤ QoS Mapping...
Resetting the modem hardware	Refer to <i>Resetting the Modem Hardware in Chapter 3</i> .	Configuration ➤ Reset ➤ Modem HW
Resetting the modem configuration	Refer to <i>Resetting the Modem Configuration in Chapter 3</i> .	Configuration ➤ Reset ➤ Configuration
Resetting the Line Configuration	Refer to <i>Resetting the Line Configuration in Chapter 3</i> .	Configuration ➤ Reset ➤ Line
Testing the modem diagnostics	<i>Test Dialog Box</i> Refer to <i>Testing the Modem Diagnostics in Chapter 3</i> .	Diagnostics ➤ Test...
Configuring BERT testing	<i>BERT Counters Dialog Box</i> Refer to <i>Configuring BERT Testing in Chapter 3</i> .	Diagnostics ➤ BERT Counters...
Task – Statistics	Dialog Box and/or Parameter Location	Path
Clearing modem statistics	Refer to <i>Clearing Modem Statistics in Chapter 4</i> .	Statistics ➤ Clear Modem Statistics...

1.5 SHDSL Link Port Level Operations

Table 1-6 lists the different management options for the SHDSL Link port level.

Table 1-6. SHDSL Link Port Management Options

Task – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms at the SHDSL Link port level	<i>Port Active Alarm List Dialog Box</i> Refer to <i>Displaying the Active Alarms at the SHDSL Link Port Level</i> in <i>Chapter 2</i> .	Fault ➤Active Alarms...
Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the SHDSL Link port parameters	<i>Port Parameters Dialog Box</i> Refer to <i>Configuring the SHDSL Link Port Parameters</i> in <i>Chapter 3</i> .	Configuration ➤Parameters...
Viewing the SHDSL Link port status configuration	<i>Port Status Dialog Box</i> Refer to <i>Viewing the SHDSL Link Port Status Configuration</i> in <i>Chapter 3</i> .	Configuration ➤Status...
Tasks – Statistics	Dialog Box and/or Parameter Location	Path
Viewing port data from the beginning of the current 15-minute interval	<i>15 min Current Data Dialog Box</i> Refer to <i>Viewing Current 15-Minute Data for the SHDSL Link Port</i> in <i>Chapter 4</i> .	Statistics ➤Line ➤15 min Current Data...
Viewing port data from the beginning of the current one-day interval	<i>One Day Current Data Dialog Box</i> Refer to <i>Viewing One-Day Current Data for the SHDSL Link Port</i> in <i>Chapter 4</i> .	Statistics ➤Line ➤One Day Current Data...
Viewing port data for all 15-minute intervals over the last 24 hours	<i>15 min Interval Data Dialog Box</i> Refer to <i>Viewing 15-Minute Interval Data for the SHDSL Link Port</i> in <i>Chapter 4</i> .	Statistics ➤Line ➤15 min Interval Data
Viewing port data at one-day intervals	<i>One Day Interval Data Dialog Box</i> Refer to <i>Viewing One-Day Interval Data for the SHDSL Link Port</i> in <i>Chapter 4</i> .	Statistics ➤Line ➤One Day Interval Data...
Viewing accumulated data for the SHDSL link port	<i>Accumulated Data Dialog Box</i> Refer to <i>Viewing Accumulated Data for the SHDSL Link Port</i> in <i>Chapter 4</i> .	Statistics ➤Line ➤Accumulated Data...

Table 1-6. SHDSL Link Port Management Options (Cont.)

Task – Statistics	Dialog Box and/or Parameter Location	Path
Clearing port statistics at the SHDSL Link port level	Refer to Clearing Statistics for the SHDSL Link Port in Chapter 4 .	Statistics ➡Clear Statistics...

1.6 ETH Port Level Operations

[Table 1-7](#) lists the different management options for the ETH port level.

Table 1-7. ETH Port Management Options

Task – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms at the ETH port level	Port Active Alarm List Dialog Box Refer to Displaying the Active Alarms at the ETH Port Level in Chapter 2 .	Fault ➡Active Alarms...
Task – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the ETH port parameters	Port Parameters Dialog Box Refer to Configuring the ETH Port Parameters in Chapter 3 .	Configuration ➡Parameters...

1.7 E1 and T1 Port Level Operations

[Table 1-8](#) lists the different management options for the E1 and T1 port levels.

Table 1-8. E1 and T1 Port Management Options

Task – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms at the E1 port level	Port Active Alarm List Dialog Box Refer to Displaying the Active Alarms at the E1 Port Level in Chapter 2 .	Fault ➡Active Alarms...

Table 1-8. E1 and T1 Port Management Options (Cont.)

Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the parameters for the E1 port	<i>Port Parameters Dialog Box</i> Refer to <i>Configuring the Parameters for the E1 Port</i> in Chapter 3.	Configuration ➡Parameters...
Configuring the parameters for the T1 port	Refer to <i>Configuring the Parameters for the T1 Port</i> in Chapter 3.	Configuration ➡Parameters...
Tasks – Statistics	Dialog Box and/or Parameter Location	Path
Viewing BPV statistics	<i>BPV Statistics Dialog Box</i> Refer to <i>Viewing BPV Statistics</i> in Chapter 4.	Statistics ➡BPV...
Viewing current 15-minute port data	<i>15 min Current Data Dialog Box</i> Refer to <i>Viewing Current 15-Minute Port Data</i> in Chapter 4.	Statistics ➡15 min Current Data...
Viewing 15-minute interval port data	<i>15 min Interval Data Dialog Box</i> Refer to <i>Viewing 15-Minute Interval Port Data</i> in Chapter 4.	Statistics ➡15 min Interval Data...
Clearing statistics for the E1/T1 port	Refer to <i>Clearing Statistics for the E1/T1 Port</i> in Chapter 4.	Statistics ➡Clear Statistics...

1.8 DTE (V.35, X.21, RS-530) Port Levels Operations

Table 1-9 lists the different management options for the DTE (V.35, X.21, RS-530) port levels.

Table 1-9. DTE (V.35, X.21, RS-530) Port Management Options

Task – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms at the DTE (V.35, X.21, RS-530) port levels	<i>Port Active Alarm List Dialog Box</i> Refer to <i>Displaying the Active Alarms at the DTE (V.35, X.21, RS-530, IR-IP) Port Levels</i> in Chapter 2.	Fault ➡Active Alarms...
Task – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the DTE (V.35, RS-530) port parameters	<i>Port Parameters Dialog Box</i> Refer to <i>Configuring the DTE (V.35, RS-530) Port Parameters</i> in Chapter 3.	Configuration ➡Parameters...

1.9 CONTROL Port Level Operations

Table 1-10 lists the different management options for the CONTROL port level.

Table 1-10. CONTROL Port Management Options

Task – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the CONTROL port parameters	<i>Port Parameters Dialog Box</i> Refer to <i>Configuring the CONTROL Port Parameters</i> in <i>Chapter 3</i> .	Configuration ➔Parameters...

1.10 Repeater Level Operations

Table 1-11 lists the different management options for the repeater level.

Table 1-11. Repeater Management Options

Tasks – Fault	Dialog Box and/or Parameter Location	Path
Displaying the active alarms at the repeater level	<i>Repeater Active Alarm List Dialog Box</i> Refer to <i>Displaying the Active Alarms at the Repeater Level</i> in <i>Chapter 2</i> .	Fault ➔Active Alarms...
Displaying the history log	<i>Repeater Alarm Buffer List Dialog Box</i> Refer to <i>Displaying the History Log</i> in <i>Chapter 2</i> .	Fault ➔History Log ➔List...
Tasks – Configuration	Dialog Box and/or Parameter Location	Path
Configuring the repeater parameters	<i>Repeater Parameters Dialog Box</i> Refer to <i>Configuring the Repeater Parameters</i> in <i>Chapter 2</i> .	Configuration ➔Parameters...
Resetting the repeater network side	Refer to <i>Resetting the Repeater Network Side</i> in <i>Chapter 2</i> .	Configuration ➔Reset Network Side
Tasks – Diagnostics	Dialog Box and/or Parameter Location	Path
Testing the repeater diagnostics	<i>Repeater Test Dialog Box</i> Refer to <i>Testing the Repeater Diagnostics</i> in <i>Chapter 2</i> .	Diagnostics ➔Test...

Chapter 2

Fault Management

This chapter describes ASMi-52 fault management at the system, modem, port, and repeater levels.

2.1 System Level – Fault Menu

The **Fault** menu provides access to the system alarm options.




Figure 2-1. System Level Fault Menu

Masking the Alarms

The **Mask Alarms** command enables you to mask the alarms of all modems and repeaters.

➤ **To mask the alarms of all modems and repeaters:**

1. At the system level, select **Fault > Mask Alarms...**




Figure 2-2. Mask Alarms Dialog Box

2. Select or deselect the Mask Alarms checkbox and click **<Set>**.

Note If you mask an alarm, it will not appear in the alarm list or history log. In addition, no alarm trap will be sent for the corresponding port.

Clearing the History Log

The **History Log > Clear All** command enables you to clear all entries in the alarm buffer.

➤ **To clear all entries in the alarm buffer:**

- At the system level, select **Fault > History Log > Clear All**.

All entries in the alarm buffer are cleared.

2.2 Modem Level – Fault Menu

The **Fault** menu allows you to display the active alarms at the modem level. You can view the active alarms for modems and ports, or for modems only.




Figure 2-3. Modem Level Fault Menu

Displaying the Active Alarms for Modems and Ports

The **Active Alarms > Modems & Ports** command enables you to display the active alarms of the selected modem at both the modem and port levels.

- **To display the active alarms at all levels:**
 - At the modem level, select **Fault > Active Alarms > Modems & Ports...**

Note You can sort the Active Alarm List by clicking any of the column headings.




Figure 2-4. All Modem Active Alarm List Dialog Box

Table 2-1. All Modem Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Port	The port reporting the alarm
Code	Alarm code 1...43, 50, 51, 60...66
Description	Description of the alarm <i>Note: See Appendix A for a full list of alarm descriptions</i>
Severity	Major, Minor, Warning
[Close]	Click <Close> to close the All Modem Active Alarm List dialog box
[Save to File...]	Click <Save to File...> to save the All Modem Active Alarm List to a file <i>Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)</i>
[Print...]	Click <Print...> to print the All Modem Active Alarm List
[Refresh]	Click <Refresh> to update the All Modem Active Alarm List dialog box

Displaying the Active Alarms at the Modem Level

The **Active Alarms > Modem Level** command enables you to display the active alarms at the modem level.

- **To display the active alarms at the modem level:**
 - At the modem level, select **Fault > Active Alarms > Modem Level...**




Figure 2-5. Modem Active Alarm List Dialog Box

Table 2-2. Modem Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 1, 2, 20, 23, 42, 43, 51, 60...66
Description	Description of the alarm Note: See Appendix A for a full list of alarm descriptions
Severity	Major, Minor, Warning
[Close]	Click <Close> to close the Modem Active Alarm List dialog box
[Save to File...]	Click <Save to File...> to save the Modem Active Alarm List to a file Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)

Table 2-2. Modem Active Alarm List Parameters (Cont.)

Parameter	Possible Values / Remarks
[Print...]	Click < Print... > to print the Modem Active Alarm List
[Refresh]	Click < Refresh > to update the Modem Active Alarm List dialog box

Displaying the History Log

The **History Log > List** command enables you to display the history log for the active alarms at the modem level.

- **To display the history log for the active alarms at the modem level:**
 - At the modem level, select **Fault > History Log > List...**




Figure 2-6. Modem Alarm Buffer List Dialog Box

Table 2-3. Modem Alarm Buffer List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 1...43, 50, 51, 60...66
Description	Description of the alarm Note: See Appendix A for a full list of alarm descriptions
State	Off, On
Date	The date of the alarm, in the format YYYY-MM-DD
Time	The time of the alarm, in the format HH:MM:SS
[Close]	Click <Close> to close the Modem Alarm Buffer List dialog box
[Save to File...]	Click <Save to File...> to save the Modem Alarm Buffer List to a file Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)
[Print...]	Click <Print...> to print the Modem Alarm Buffer List
[Refresh]	Click <Refresh> to update the Modem Alarm Buffer List dialog box

2.3 SHDSL Link Port Level – Fault Menu

The **Fault** menu allows you to display the active alarms at the SHDSL Link port level.



Figure 2-7. SHDSL Link Port Level Fault Menu

Displaying the Active Alarms at the SHDSL Link Port Level

The **Active Alarms** command enables you to display the active alarms at the SHDSL Link port level.

- **To display the active alarms at the SHDSL Link port level:**
 - At the SHDSL Link port level (NE or FE), select **Fault > Active Alarms...**




Figure 2-8. Port Active Alarm List Dialog Box

Table 2-4. Port Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 3, 6, 9...14, 16...19, 21, 22, 50
Description	Description of the alarm Note: See Appendix A for a full list of alarm descriptions
Severity	Major, Minor, Warning
[Close]	Click <Close> to close the Port Active Alarm List dialog box
[Save to File...]	Click <Save to File...> to save the Port Active Alarm List to a file Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)
[Print...]	Click <Print...> to print the Port Active Alarm List
[Refresh]	Click <Refresh> to update the Port Active Alarm List dialog box

2.4 ETH Port Level – Fault Menu

The **Fault** menu allows you to display the active alarms at the ETH port level.



Figure 2-9. ETH Port Level Fault Menu

Displaying the Active Alarms at the ETH Port Level

The **Active Alarms** command enables you to display the active alarms at the ETH port level.

- **To display the active alarms at the ETH port level:**
 - At the ETH port level (NE or FE), select **Fault > Active Alarms...**




Figure 2-10. Port Active Alarm List Dialog Box

Table 2-5. Port Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52A, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 8
Description	Description of the alarm <i>Note: See Appendix A for a full list of alarm descriptions</i>
Severity	Major, Minor, Warning
[Close]	Click <Close> to close the Port Active Alarm List dialog box
[Save to File...]	Click <Save to File...> to save the Port Active Alarm List to a file <i>Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)</i>
[Print...]	Click <Print...> to print the Port Active Alarm List
[Refresh]	Click <Refresh> to update the Port Active Alarm List dialog box

2.5 E1 and T1 Port Levels – Fault Menu

The **Fault** menu allows you to display the active alarms at the E1 and T1 port levels.



Figure 2-11. E1 and T1 Port Level Fault Menu

Displaying the Active Alarms at the E1 Port Level

The **Active Alarms** command enables you to display the active alarms at the E1 and T1 port levels.

- To display the active alarms at the E1 and T1 port levels:
 - At the E1/T1 port level (NE or FE), select **Fault > Active Alarms...**




Figure 2-12. Port Active Alarm List Dialog Box

Table 2-6. Port Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 7, 24...41
Description	Description of the alarm Note: See Appendix A for a full list of alarm descriptions
Severity	Major, Minor, Warning
[Close]	Click <Close> to close the Port Active Alarm List dialog box
[Save to File...]	Click <Save to File...> to save the Port Active Alarm List to a file Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)
[Print...]	Click <Print...> to print the Port Active Alarm List
[Refresh]	Click <Refresh> to update the Port Active Alarm List dialog box

2.6 DTE (V.35, X.21, RS-530, IR-IP) Port Levels – Fault Menu

The **Fault** menu allows you to display the active alarms at the DTE (V.35, X.21, RS-530, IR-IP) port levels.



Figure 2-13. DTE (V.35, X.21, RS-530, IR-IP) Port Level Fault Menu

Displaying the Active Alarms at the DTE (V.35, X.21, RS-530, IR-IP) Port Levels

The **Active Alarms** command enables you to display the active alarms at the DTE (V.35, X.21, RS-530, IR-IP) port levels.

- **To display the active alarms at the DTE (V.35, X.21, RS-530, IR-IP) port levels:**
 - At the DTE (V.35, X.21, RS-530, IR-IP) port level, select **Fault > Active Alarms...**




Figure 2-14. Port Active Alarm List Dialog Box

Table 2-7. Port Active Alarm List Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Code	Alarm code 4, 5, 8, 15, 51 <i>Note: Bits 4 and 5 are only relevant for V.35/RS-530</i> <i>Note: Bit 8 is only relevant for IR-IP</i>
Description	Description of the alarm <i>Note: See Appendix A for a full list of alarm descriptions</i>
Severity	Major, Minor, Warning
[Close]	Click < Close > to close the Active Alarm List dialog box
[Save to File...]	Click < Save to File... > to save the Port Active Alarm List to a file <i>Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm).</i>
[Print...]	Click < Print... > to print the Port Active Alarm List
[Refresh]	Click < Refresh > to update the Port Active Alarm List

2.7 Repeater Level – Fault Menu

The **Fault** menu allows you to display active alarms at the repeater level.




Figure 2-15. Repeater Level Fault Menu

Displaying the Active Alarms at the Repeater Level

The **Active Alarms** command enables you to display the active alarms at the repeater level.

➤ **To display the active alarms at the repeater level:**

1. In the RADview ASMi-52 window, select a repeater.
2. Select **Fault > Active Alarms...**

Note You can sort the Active Alarm List by clicking any of the column headings.




Figure 2-16. Repeater Active Alarm List Dialog Box

Table 2-8. Repeater Active Alarm List Parameters

Parameter	Possible Values / Remarks
Repeater	1...8
Code	Alarm code 44...49
Description	Description of the alarm <i>Note: See Appendix A for a full list of alarm descriptions</i>
Severity	Major, Minor, Warning
[Close]	Click < Close > to close the Repeater Active Alarm List dialog box
[Save to File...]	Click < Save to File... > to save the Repeater Active Alarm List to a file <i>Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)</i>
[Print...]	Click < Print... > to print the Repeater Active Alarm List
[Refresh]	Click < Refresh > to update the Repeater Active Alarm List dialog box

Displaying the History Log

The **History Log > List** command enables you to display the history log for alarms at the repeater level.

► **To display the history log for alarms at the repeater level:**

1. In the RADview ASMi-52 window, select a repeater.
2. Select **Fault > History Log > List...**




Figure 2-17. Repeater Alarm Buffer List Dialog Box

Table 2-9. Repeater Alarm Buffer List Parameters

Parameter	Possible Values / Remarks
Repeater	1...8
Code	Alarm code 44...49
Description	Description of the alarm <i>Note: See Appendix A for a full list of alarm descriptions</i>
State	On, Off
Date	The date of the alarm, in the format YYYY-MM-DD
Time	The time of the event, in the format HH:MM:SS

Table 2-9. Repeater Alarm Buffer List Parameters (Cont.)

Parameter	Possible Values / Remarks
[Close]	Click < Close > to close the Repeater Alarm Buffer List dialog box
[Save to File...]	Click < Save to File... > to save the Repeater Alarm Buffer List to a file <i>Note: In the File of type field, select Acrobat (*.pdf) or HTML (*.htm)</i>
[Print...]	Click < Print... > to print the Repeater Alarm Buffer List
[Refresh]	Click < Refresh > to update the Repeater Alarm Buffer List dialog box

Chapter 3

Configuration Management

The chapter describes the ASMi-52 configuration management at the system, modem, port, and repeater levels.

3.1 System Level – Configuration Menu

The system level **Configuration** menu provides you with options for viewing and modifying system configuration.





Figure 3-1. System Level Configuration Menu

Viewing and Setting System Information

The **System Info** command enables you to view and set general information about the system.

► **To view and set system information:**

1. At the system level, select **Configuration > System Info...**
or
From the Toolbar, click .
2. Configure the desired parameters and click **<Set>**.




Figure 3-2. System Information Dialog Box

Table 3-1. System Information Parameters

Parameter	Possible Values / Remarks
Description	Description of the device, including hardware and software versions
Object ID	Device's SNMP Object ID
Name	Name of the device, a string of up to 12 characters
Contact	Name of the person responsible for the functioning of this device, a string of up to 32 characters
Location	Exact location of this device, a string of up to 32 characters
System Up Time	Amount of time that elapsed since this device was reset, in the format X days HH:MM:SS
Number of Interfaces	Number of physical and logical interfaces on this device
[Set]	Click <Set> to set the system information configuration parameters
[Cancel]	Click <Cancel> to close the System Information dialog box
[Refresh]	Click <Refresh> to update the System Information dialog box

Polling the Agent

The **Poll Agent** command enables you to poll the Agent immediately.

► To poll the Agent:

- At the system level, select **Configuration > Poll Agent**.
or
From the Toolbar, click .

The system immediately polls the Agent and updates the displayed information.

3.2 System Level – Options Menu

The Options menu allows you to view and configure the Host Interface List, the Manager List, and enable the polling option.




Figure 3-3. System Level Options Menu

Viewing the Host Interface List

The **Host Interface List** command enables you to view and configure the Host Interface List.

➤ **To display the Host Interface List:**

- At the system level, select **Options > Host Interface List...**




Figure 3-4. Host Interface List Dialog Box

Table 3-2. Host Interface List Parameters

Parameter	Possible Values / Remarks
Host	The name of the Host ETH, Dedicated TS
IP Address	The IP address of the Host Note: An IP address of 0.0.0.0 indicates there is no Host
IP Mask	The IP Mask of the Host Note: An IP address of 0.0.0.0 indicates there is no Host
Host Tagging	Tagged, Untagged
Host VLAN ID	1...4094
Host Priority Tag	0...7
[Change]	Click < Change > to open the dialog box
[Close]	Click < Close > to close the Host Interface List dialog box
[Refresh]	Click < Refresh > to update the Host Interface List dialog box

Configuring Host Interface

➤ **To configure host interface:**

- At the system level, select Options > Host Interface List...
- Select the host interface you want to configure and click <**Change...**>.
- Configure the desired parameters and click <**Set**>.




Figure 3-5. Host Interface Change Dialog Box

Table 3-3. Host Interface Change Parameters

Parameter	Possible Values / Remarks
Host	The name of the Host ETH, Dedicated TS
IP Address	The IP address of the Host Note: An IP address of 0.0.0.0 indicates there is no Host
IP Mask	The IP Mask of the Host Note: An IP address of 0.0.0.0 indicates there is no Host
Host Tagging	Tagged, Untagged Note: This field only exists if the Host type is ETH
[Set]	Click < Set > to set the configured parameters
[Cancel]	Click < Cancel > to close the Host Interface Change dialog box

Configuring the Manager List

The **Manager List** command enables you to configure the Manager List.

➤ **To display the Manager List:**

- At the system level, select **Options > Manager List...**

Manager Id	IP Address	IP Mask
1	172.17.150.29	255.255.255.0
2	172.17.150.38	255.255.255.0
3	0.0.0.0	0.0.0.0
4	0.0.0.0	0.0.0.0
5	0.0.0.0	0.0.0.0
6	0.0.0.0	0.0.0.0
7	0.0.0.0	0.0.0.0
8	0.0.0.0	0.0.0.0
9	0.0.0.0	0.0.0.0
10	0.0.0.0	0.0.0.0

Buttons: Set, Cancel, Refresh

Status: Ready

Figure 3-6. Manager List Dialog Box

Table 3-4. Manager List Parameters

Parameter	Possible Values / Remarks
Manager Id	The number of the Manager Id 1...10
IP Address	The IP address of the Manager Note: An IP address of 0.0.0.0 indicates there is no Manager
IP Mask	The IP Mask of the Manager Note: An IP address of 0.0.0.0 indicates there is no Manager
[Set]	Click <Set> to set the Manager List parameters
[Cancel]	Click <Cancel> to close the Manager List dialog box
[Refresh]	Click <Refresh> to update the Manager List dialog box

Setting the Polling Option

The **Polling** command enables you to toggle polling on/off.

➤ **To set the polling option:**

- At the system level, select **Options > Polling**.

Polling is enabled, and the Agent is polled every 60 seconds.

Note When polling is enabled, a checkmark appears to the left of the Polling menu item. When polling is disabled, a checkmark does not appear.

3.3 Modem Level – Configuration Menu

The modem level **Configuration** menu allows you to view and set modem configuration.




Figure 3-7. Modem Level Configuration Menu

Viewing Modem Information

The **Modem Info** command enables you to view modem information.

Note The parameters listed below do not appear for an unmanaged FE modem.

➤ **To view modem information:**

- At the modem level, select **Configuration > Modem Info...**
- or
- From the Toolbar, click .




Figure 3-8. Modem Information Dialog Box

Table 3-5. Modem Information Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
SW Version	The software version of the modem
HW Version	The hardware version of the modem
IP Address	The IP address of the modem
[Close]	Click <Close> to close the Modem Information dialog box
[Refresh]	Click <Refresh> to update the data in the Modem Information dialog box

Configuring the Modem Parameters

The **Modem Parameters** command enables you to configure the modem parameters.

Note This command is not available for an unmanaged FE modem.

► **To configure modem parameters:**

1. At the modem level, select **Configuration > Modem Parameters...**
2. Configure the desired parameters and click <Set>.




Figure 3-9. Modem Parameters Dialog Box

Table 3-6. Modem Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Interface Data Traffic	
E1/T1 Enable	Checked, Unchecked
DTE Enable	Checked, Unchecked
ETH Enable	Checked, Unchecked
Clock Source	
Mode	Internal, External, Receive <i>Note:</i> This field is read-only for the FE modem <i>Note:</i> If you lose synchronization between the NE and FE modems (which occurs when the value for both of them is Receive), change the Receive value for one modem to another value
Port	E1/T1, DTE <i>Note:</i> This field is read-only for the FE modem
Wiring	2 Wire, 4 Wire <i>Note:</i> This field is read-only for a 2-wire modem
Low Speed	No, Yes, 0, --- <i>Note:</i> This field is disabled only for an NE modem with existing DTE or a LAN connection <i>Note:</i> This field is read-only if one of the ports has a MUX option or is of type E1/T1
Default Gateway	The IP address of the default gateway for the modem <i>Note:</i> This field is disabled for the FE modem
[Set]	Click <Set> to set the modem configuration parameters
[Cancel]	Click <Cancel> to close the Modem Parameters dialog box
[Refresh]	Click <Refresh> to update the Modem Parameters dialog box

Viewing Available Bandwidth

The **Bandwidth Allocation** command enables you to view available bandwidth and define time slot assignments.

Note This command is not available for an unmanaged FE modem.

- **To view available bandwidth:**
 - At the modem level, select **Configuration > Bandwidth Allocation...**




Figure 3-10. Bandwidth Allocation Dialog Box

Table 3-7. Bandwidth Allocation Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Rate	
ETH	Enabled when a data port is Ethernet. Select the required data rate from the available values. See Table 3-8 and Table 3-9 for the available data rates
DTE	Enabled when a data port is Serial DTE. Select the required data rate from the available values. See Table 3-8 and Table 3-9 for the available data rates In order to increase the possible bandwidth allocation user lower E1/T1 timeslots.
E1/T1	Enabled when a data port is E1/T1. Select the required data rate from the available values. See Table 3-8 and Table 3-9 for the available data rates
TSA	Click <TSA> to open the Time Slot Assignments dialog box
Far-End E1 TSs	0...31 This parameter is used to define the time slots when the remote modem is not connected, or is an ASMi-52 multiplexer unit. This parameter is available in version 2.5 and above units only. Set the parameter when the local modem is STU-C and E1 line type is unframed
[Set]	Click <Set> to set the modem configuration parameters
[Cancel]	Click <Cancel> to close the Modem Parameters dialog box
[Refresh]	Click <Refresh> to update the Modem Parameters dialog box

Table 3-8. ASMi-52 Data Rates

DTE Interface and Clock Mode		Line Interface	
Local ASMi-52	Remote ASMi-52	2-wire	4-wire
Serial DTE interface, internal clock	Serial DTE interface	$n \times 64$ kbps ($n = 1, 2, \dots, 32, 36$)	$n \times 128$ kbps ($n = 1, 2, \dots, 32, 36$)
Serial DTE interface, external clock	Serial DTE interface	$n \times 64$ kbps ($n = 1, 2, \dots, 36$)	$n \times 128$ kbps ($n = 1, 2, \dots, 36$)
Serial DTE interface	E1 DTE interface	$n \times 64$ kbps ($n = 3, 4, \dots, 32$)	$n \times 128$ kbps ($n = 3, 4, \dots, 16$)
E1 DTE interface	Serial DTE interface	$n \times 64$ kbps ($n = 3, 4, \dots, 32$)	$n \times 128$ kbps ($n = 3, 4, \dots, 16$)
E1 DTE interface	E1 DTE interface	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)
T1 DTE interface	T1 DTE interface	$n \times 64$ kbps ($n = 1, 2, \dots, 24$)	$n \times 64$ kbps ($n = 1, 2, \dots, 24$)
Multiplexer	Serial/E1 DTE (any) interface	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)

Table 3-9. ASMi-52 Data Rates (Low Speed Mode)

Unit and DTE Interface Type		Line Interface	
Local Unit	Remote Unit	2-wire	4-wire
ASMi-52 in low speed mode	ASMi-52 in low speed mode	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)
	ASMi-52 with serial DTE interface	$n \times 64$ kbps ($n = 3, 4, \dots, 32$)	$n \times 128$ kbps ($n = 3, 4, \dots, 16$)
	ASMi-52 with E1 DTE interface	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)	$n \times 64$ kbps ($n = 1, 2, \dots, 32$)

Defining the Time Slot Assignment

The **TS Assignment** command enables you to define the time slots at the E1 and T1 port levels.

Note All time slot values for the FE modem are read-only.

➤ To define the time slot at the E1 and T1 port levels:

1. At the modem level, select **Configuration > Bandwidth Allocation...**
2. Click **TSA...** in the E1/T1 field.
3. Configure the desired parameters and click **<OK>**.

172.17.155.46-t1 : 172.17.155.46-t1 : T1 TSA

Location: Near-End

SHDSL Mode: STU-C

Port: T1

Far-End Modem Type: Unknown

Near End Modem

T1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
To SHDSL Line	D		D																					

Far End Modem (RO)

T1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
To SHDSL Line																								

OK Cancel Group... Data Mng Disconnect Reset All Refresh

Figure 3-11. T1 TSA Dialog Box

172.17.152.139 : 172.17.152.139 : E1 TSA

Location: Near-End

SHDSL Mode: STU-C

Port: E1

Far-End Modem Type: ASMi-52

Near End Modem

E1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
To SHDSL Line	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	

Far End Modem (RO)

E1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
To SHDSL Line	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	

OK Cancel Group... Data Mng Disconnect Reset All Refresh

Ready

Figure 3-12. E1 TSA Dialog Box

Table 3-10. E1 (or T1) TSA Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	E1, T1
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL

Parameter	Possible Values / Remarks
[OK]	Click <OK> to set the time slot configuration parameters as displayed in the Near End Modem and Far End Modem tables <i>Note: This button is disabled if only one port is supported</i> <i>Note: If you remove all table values of type Mng TS, a warning message will appear indicating that the Agent may be disconnected</i>
[Cancel]	Click <Cancel> to close the E1 (or T1) TSA dialog box
[Group...]	Click <Group...> to define time slot groups <i>Note: This button is only enabled when no table cell is selected</i> Refer to Defining Time Slot Groups
[Data]	Click <Data> to change the TS type of the selected time slot to Data <i>Note: This button is only enabled when a lower gray table cell is selected</i>
[Mng]	Click <Mng> to change the TS type of the selected time slot to Mng <i>Note: This button is only enabled when the Inband Mng value in the Port Parameters Dialog Box is not None, and when a lower gray table cell is selected</i> Refer to Configuring the Parameters for the E1 Port
[Disconnect]	Click <Disconnect> to remove a time slot connection <i>Note: This button is only enabled when a yellow or green table cell is selected</i>
[Reset All]	Click <Reset All> to remove all time slot connections <i>Note: A warning message will appear</i>
[Refresh]	Click <Refresh> to update the data in the E1 (or T1) TSA dialog box

Defining Time Slot Groups

The **Group** button enables you to define time slot groups.

Note This command is not available for the FE modem.

➤ To define time slot groups:

1. At the modem level, select Configuration > Bandwidth Allocation...
2. Click **TSA...** in the E1/T1 field.
3. Click **<Group...>**.
4. Configure the desired parameters and click **<OK>**.




Figure 3-13. Group Connection Dialog Box

Table 3-11. Group Connection Parameters

Parameter	Possible Values / Remarks
Connect	
All	Click the radio button to the left of <All> to transfer all time slots to the G.SHDSL line Note: The No. of TSs and Start TS fields will be disabled
Sequence	Click the radio button to the left of <Sequence> to specify a specific time slot sequence Note: The No. of TSs and Start TS fields will be enabled
Start TS	The first time slot in the group 1...31 (E1) 1...24 (T1) Default: 1 Note: If the Line Type value in the Port Parameters Dialog Box is E1-MF (G732S) or E1-CRC-MF (G732SCRC), you cannot select the value 16 for this field Refer to Configuring the Parameters for the E1 Port
No. of TSs	The total number of time slots in the group 1...31 (E1) 1...24 (T1) Default: 1
[OK]	Click <OK> to set the time slot group parameters
[Cancel]	Click <Cancel> to close the Group Connection dialog box

Configuring the LAN

The **LAN Configuration** command enables you to configure the LAN.

Note This command is not available for an unmanaged FE modem.

► To configure the LAN:

1. At the modem level, select Configuration > LAN Configuration...
2. Configure the desired parameters and click **<Set>**.




Figure 3-14. LAN Configuration Dialog Box

Table 3-12. LAN Configuration Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Operation Mode	Bridge <i>Note: This field is read-only</i>
Aging Time (sec)	10...1000000 Default: 10 <i>Note: This field is disabled when the Operation Mode is Transparent</i>
Bridging Mode	Access & Switch, Access Only Default: Access & Switch <i>Note: This field is read-only</i>
[Set]	Click <Set> to update the Aging Timeout (sec) and Operation Mode fields
[Cancel]	Click <Cancel> to close the LAN Configuration dialog box
[Refresh]	Click <Refresh> to update the data in the LAN Configuration dialog box

Configuring the Bridging Table

The **Bridging Table** command enables you to configure the Bridging Table.

Note This command is not available for an unmanaged FE modem.

► To configure the Bridging Table:

1. At the modem level, select **Configuration > Bridging Table...**
2. Configure the desired parameters and click <Set>.




Figure 3-15. Bridging Table Dialog Box

Table 3-13. Bridging Table Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Mac Address	MAC address of the bridging table
Port	LAN, SHDSL, E1 or T1
Type	Learned, Static
[Add...]	Click <Add> to add a static entry to the Bridging Table Refer to Adding a Static Entry to the Bridging Table
[Remove]	Click <Remove> to delete a selected static entry from the Bridging Table
[Remove All]	Click <Remove All> to remove all selected static entries
[Close]	Click <Close> to close the Bridging Table dialog box
[Refresh]	Click <Refresh> to update the data in the Bridging Table dialog box

Adding a Static Entry to the Bridging Table

The **Add** button in the Bridging Table dialog box enables you to add a static entry to the table.

➤ **To add a static entry to the Bridging Table:**

1. At the modem level, select **Configuration > Bridging Table...**
2. Click **<Add...>** in the Bridging Table dialog box.




Figure 3-16. Bridging Table: Add Static Entry Dialog Box

Table 3-14. Bridging Table: Add Static Entry Parameters

Parameter	Possible Values / Remarks
Mac Address (Hex)	MAC address of the static entry
Port	LAN (Near-End), SHDSL (Near-End), E1/T1 (Near-End) Default: LAN (Near-End) Note: This field displays a value only when a port physically exists in the modem
[Apply]	Click <Apply> to add the new entry to the Bridging Table
[Close]	Click <Close> to close the Bridging Table: Add Static Entry dialog box

Configuring QoS Mapping




Figure 3-17. QoS Mapping Dialog Box

Table 3-15. QoS Mapping Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Classification	802.1p
Mapping	
User Priority	0...7
Traffic Class	0...3
[Set]	Click <Set> to update the Traffic Class field
[Traffic Class]	When clicked this opens a sub-menu with the following values: 0 (= High) 1 2 3 (=Low) Selecting one of these sub-entries updates the Traffic Class value of the selected cell. Note: This field is only enabled when a cell is selected.
[Cancel]	Click <Cancel> to close the QoS Mapping dialog box
[Refresh]	Click <Refresh> to update the QoS Mapping dialog box

Resetting the Configuration

The **Reset** command enables you to reset the modem hardware, the modem configuration, and the modem line.

Note *These commands are not available for an unmanaged or unknown FE modem.*

Resetting the Modem Hardware

The **Reset > Modem HW** command enables you to reset the modem hardware.

➤ **To reset the modem hardware:**

- At the modem level, select **Configuration > Reset > Modem HW**.

The modem hardware is reset.

Resetting the Modem Configuration

The **Reset > Configuration** command enables you to reset the modem configuration.

➤ **To reset the modem configuration:**

- At the modem level, select **Configuration > Reset > Configuration**.

The modem configuration is reset.

Resetting the Line Configuration

The **Reset > Line** command enables you to reset the line configuration.

➤ **To reset the line configuration:**

- At the modem level, select **Configuration > Reset > Line**.

The line configuration is reset.

3.4 Modem Level – Diagnostics Menu

The modem level **Diagnostics** menu allows you to test modem diagnostics.




Figure 3-18. Modem Level Diagnostics Menu

Testing the Modem Diagnostics

The **Test** command enables you to test the modem diagnostics.

Note *This command is not available for the FE modem.*

➤ **To test the modem diagnostics:**

- At the modem level, select **Diagnostics > Test...**




Figure 3-19. Test Dialog Box

Table 3-16. Test Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Current Test	The test currently running on the port
Activate Test	None, E1 RLB or T1 RLB, E1 LLB or T1 LLB, IR RLB, IR LLB, E1+IR RLB or T1+IR RLB, E1+IR LLB or T1+IR LLB, RLB, LLB, BERT, BERT+RLB Note: Before running a new test, you must click <Stop> to stop the current test Note: You can only run a new test when the Current Test value is None
Test Duration (min)	The amount of time the test will run (in minutes) Unchecked (Test Duration disabled), Checked (Test Duration enabled) 1...4095 Note: If you insert a value outside the above range, the Status Bar will display an error message
Test Initiator	None, User, DTE
BERT Pattern	2E15-1, Alternate, Mark, Space
[Stop]	Click <Stop> to stop the test Note: This button is enabled only when the Test Initiator value is User
[Apply]	Click <Apply> to run the test Note: This button is only enabled when no test is currently running on both modems or if BERT is running on the FE modem and BERT is selected for the NE modem.
[Close]	Click <Close> to close the Test dialog box
[Refresh]	Click <Refresh> to update the Test dialog box

Configuring BERT Testing

The **BERT Counters** command enables you to test the circuit diagnostics.

Note This command is not available for the FE modem.

- **To test the circuit diagnostics:**
 - At the modem level, select **Diagnostics > BERT Counters...**

Figure 3-20. BERT Counters Dialog Box

Table 3-17. BERT Counters Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
BERT Pattern	2E15-1, Alternate, Mark, Space
Sync Status	Sync Loss, Sync
BERT Counters	Current – Displays the new updated counters Delta – Displays the difference between the new counter and the last counter

Parameter	Possible Values / Remarks
Run Time (sec)	Time elapsed since BERT started to run (sec)
Errored Seconds	Number of errored seconds detected since BERT started to run
Sync Loss (sec)	Number of times Sync Loss was detected since BERT started to run
Error Bits	Number of Error Bits detected since BERT started to run
BERT Result	Number of Error Bits divided by the total number of bits
Inject Error Command	Note: This group only exists for the NE modem
[Single]	Click < Single > to inject errors to the FE modem
[Polling]	Click < Polling > to open the Polling Interval dialog box. Select the polling interval in seconds and click < Set > to accept the change
[Close]	Click < Close > to close the BERT Counters dialog box
[Refresh]	Click < Refresh > to refresh the BERT Counters dialog box

3.5 SHDSL Link Port Level – Configuration Menu

The **Configuration** menu enables you to configure at the SHDSL Link port level.




Figure 3-21. SHDSL Link Port Level Configuration Menu

Configuring the SHDSL Link Port Parameters

The **Parameters** command enables you to configure the SHDSL Link port parameters.

➤ **To configure the SHDSL Link port parameters:**

1. At the SHDSL Link port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click <**Set**>.

192.168.239.128 : 192.168.239.128 : Port Parameters

Location: Near-End

SHDSL Mode: STU-C

Port: SHDSL Link

Far-End Modem Type: ASMi-52

SHDSL Transmission Mode: Annex B

EOC Compatible: Proprietary

Power Backoff: Enable

Line Probe Enable: Disable

Current SNR Margin (dB): -10 to 10

Worst Case SNR Margin (dB): -10 to 10

Power Spectral Density (PSD) Mask: Symmetric

Loop Attenuation Threshold (dB): 1 to 127

SNR Margin Threshold (dB): 1 to 15

Set Cancel Refresh

Ready

Figure 3-22. Port Parameters Dialog Box

Table 3-18. SHDSL Link Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
SHDSL Transmission Mode	Annex A, Annex B <i>Note: This field is read-only for the FE modem</i>
EOC Compatible	Proprietary, Standard <i>Note: This field is read-only</i>
Power Backoff	Enable, Disable

Parameter	Possible Values / Remarks
Line Probe Enable	Enable, Disable <i>Note: This field is enabled for a 2-wire NE modem with a SHDSL Mode of type STU-C</i> <i>Note: This field is read-only for the FE modem</i>
Current SNR Margin (dB)	Unchecked (Current SNR Margin disabled), Checked (Current SNR Margin enabled) -10...+10 <i>Note: This field is read-only for the NE modem, or when the Line Probe is disabled</i>
Worst Case SNR Margin (dB)	Unchecked (Worst Case SNR Margin disabled), Checked (Worst Case SNR Margin enabled) -10...+10 <i>Note: This field is read-only for the NE modem, or when the Line Probe is disabled</i>
Power Spectral Density (PSD) Mask	Symmetric, Asymmetric <i>Note: This field is read-only for the FE modem, or for a modem with an SHDSL Mode of STU-C and when the Line Probe is disabled</i>
Loop Attenuation Threshold (dB)	Unchecked (Loop Attenuation Threshold disabled), Checked (Loop Attenuation Threshold enabled) 1...127 <i>Note: This field is read-write only when the SHDSL Mode is STU-C</i>
SNR Margin Threshold (dB)	Unchecked (SNR Margin Threshold disabled), Checked (SNR Margin Threshold enabled) 1...15 <i>Note: This field is read-write only when the SHDSL Mode is STU-C</i>
[Set]	Click <Set> to set the port configuration parameters
[Cancel]	Click <Cancel> to close the Port Parameters dialog box
[Refresh]	Click <Refresh> to update the Port Parameters dialog box

Viewing the SHDSL Link Port Status Configuration

The **Status** command enables you to view the SHDSL Link port status configuration.

Note *This command does not display status values for the FE modem.*

- **To view the SHDSL Link port status configuration:**
 - At the SHDSL Link port level, select **Configuration > Status...**

Figure 3-23. Port Status Dialog Box

Table 3-19. Port Status Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Connected Modem/Port No:	For an LRS Quad card, FE modem number 1...4 For a DXC DSL card, external port number 1...n For a MP MSL card, external port number 1...n For an LRS-52 modem, 1...24 All other modems, NA <i>Note: This field is only visible for a NE modem connected to one of the above options</i>
Line Rate (Kbps)	The line rate of the port (in kilobytes per second)
Tip Ring	Normal, Reversed
Line Status	No Sync, Sync
SHDSL State	Idle Mode, Data Mode, Boot Upload, Boot Upload Done, Startup Handshake in Progress, Startup Training in Progress, Framers Sync in Progress, Local Analog Loopback in Progress, Remote Core Loopback in Progress, Local Digital Loopback in Progress, Spectrum Test in Progress

Parameter	Possible Values / Remarks
Loop Attenuation (dB)	0...127
SNR Margin (dB)	0...15
Tx Power (dBm)	The Tx Power of the port, in the format x.y 1...6500.0
Power Back Off (dB)	0...6
[Close]	Click <Close> to close the Port Status dialog box
[Refresh]	Click <Refresh> to update the Port Status dialog box

3.6 Ethernet Port Level – Configuration Menu

The **Configuration** menu enables you to configure at the ETH port level.




Figure 3-24. ETH Port Level Configuration Menu

Configuring the ETH Port Parameters

The **Parameters** command enables you to configure the ETH port parameters.

➤ **To configure the ETH port parameters:**

1. At the ETH port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click **<Set>**.




Figure 3-25. Port Parameters Dialog Box

Table 3-20. Ethernet Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
MAC Address	MAC address of the ETH port
Auto Negotiation (NE modem only)	Enable, Disable
Max Capability Advertised (NE modem only)	10 Base-T Half Duplex, 10 Base-T Full Duplex, 100 Base-TX Half Duplex, 100 Base-TX Full Duplex <i>Note: This field is available only if the auto-negotiation is enabled</i>
Default Type (NE modem only)	10 Base-T Half Duplex, 10 Base-T Full Duplex, 100 Base-TX Half Duplex, 100 Base-TX Full Duplex <i>Note: This field is available only if the auto-negotiation is disabled</i>
[Set]	Click <Set> to set the port configuration parameters
[Cancel]	Click <Cancel> to close the Parameters dialog box
[Refresh]	Click <Refresh> to update the Parameters dialog box

3.7 E1 and T1 Port Levels – Configuration Menu

The **Configuration** menu enables you to configure at the E1 and T1 port levels.





Figure 3-26. E1 (or T1) Port Level Configuration Menu

Configuring the Parameters for the E1 Port

The **Parameters** command enables you to configure the E1 port parameters.

➤ **To configure the parameters for the E1 port:**

1. At the E1 port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click <Set>.



The dialog box is titled "172.18.93.62 : Port Parameters" and contains the following fields and controls:

- Location: Near-End
- SHDSL Mode: STU-C
- Port: E1
- Far-End Modem Type: ASMi-52
- Line Type: Unframed
- Identical Setting: Yes
- TS0 Mode: Transparent
- Sync Mode: CCITT
- Idle Code (hex): FF
- Dedicated TS Configuration section:
 - Inband Mng: Dedicated TS/FR
 - Tx to Remote: Enabled

At the bottom, there are three buttons: "Set", "Cancel", and "Refresh". A status bar at the very bottom shows the word "Ready" next to a green square icon.

Figure 3-27. Port Parameters Dialog Box

Table 3-21. Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Line Type	The line type of the E1 port Unframed, E1 (G732N), E1-CRC (G732N-CRC), E1-MF (G732S) <i>Note: This field is read-only for the FE modem</i>
Identical settings	Whether the configuration settings are the same for the FE modem No, Yes <i>Note: This field is read-only for the FE modem</i>
TS0 Mode	The time slot mode of the port Looped, Transparent <i>Note: This field is read-only for the FE modem</i>
Sync Mode	The synchronization mode of the E1 port TR-62411, CCITT, FAST <i>Note: This field is read-only for the FE modem</i>
Idle Code (hex)	The idle code of the E1 port 0...FF <i>Note: This field is read-only for the FE modem</i>
Dedicated TS Configuration	
Inband Mng	The inband management type of the DTS configuration None, Dedicated TS/FR <i>Note: This field is unavailable for the FE modem</i>
Tx to Remote	Disable, Enable <i>Note: This field is available for the FE modem when it is connected to an E1</i>
[Set]	Click <Set> to set the port configuration parameters <i>Note: If you change the Line Type value to Unframed or the Same Far End Settings value to Yes (when the SHDSL Mode is of type STU-R), a confirmation message will appear indicating that the time slot assignment will be deleted</i> <i>Note: If you change one of the DTS Configuration values, a confirmation message will appear indicating that the Agent may be disconnected</i>
[Cancel]	Click <Cancel> to close the Port Parameters dialog box
[Refresh]	Click <Refresh> to update the Port Parameters dialog box

Configuring the Parameters for the T1 Port

The **Parameters** command enables you to configure the T1 port parameters.

► **To configure the parameters for the T1 port:**

1. At the T1 port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click **<Set>**.

Table 3-22. Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Line Type	The line type of the T1 port Unframed, ESF, D4 (SF)
Line Code	The line code of the T1 port B8ZS, AMI
Rx Gain	The Rx gain of the T1 port Short Haul, Long Haul
Line Mode	The line mode of the T1 port CSU, DSU
Tx Gain (dB)	The Tx gain of the T1 port 7.5, 15.0, 22.5 <i>Note: This field is only enabled when the Line Mode value is "CSU"</i>
Line Length (ft)	0-133, 134-266, 267-399, 400-533, 534-655 <i>Note: This field is only enabled when the Line Mode value is "DSU"</i>
Identical Settings	Whether the FE settings for the two ends of the T1 port line are the same No, Yes
Sync Mode	The synchronization mode of the T1 port TR-62411, CCITT, FAST
Idle Code (hex)	The idle code of the T1 port 0...FF
Signaling Mode	None, Robbed Bit
Dedicated TS Configuration	
Inband Mng	The inband management type of the DTS configuration None, Dedicated TS/FR
Tx to Remote	Disable, Enable <i>Note: This field is available for the FE modem when it is connected to an E1</i>

Parameter	Possible Values / Remarks
[Set]	<p>Click <Set> to set the port configuration parameters</p> <p>Note: If you changed the Line Type value to “Unframed” or the Same Far End Settings value to “Yes”, then a confirmation message appears indicating that the time slot assignment will be deleted</p> <p>Note: If you changed one of the DTS Configuration values, a confirmation message appears indicating that these changes may disconnect the Agent</p>
[Cancel]	Click <Cancel> to cancel the setting of the port configuration parameters
[Refresh]	Click <Refresh> to update the data in the Port Parameters dialog box

3.8 DTE (V.35, RS-530) Port Level – Configuration Menu

The **Configuration** menu enables you to configure at the DTE (V.35, RS-530) port level.




Figure 3-28. DTE (V.35, RS-530) Level Configuration Menu

Configuring the DTE (V.35, RS-530) Port Parameters

The **Parameters** command enables you to configure the parameters for the DTE (V.35, RS-530) port.

Note This command is not available for the DTE (X.21) port.

Note The Enable LLB from DTE and Enable RLB from DTE checkboxes that appear below are disabled for the FE modem when it is unmanaged or unknown.

➤ **To configure the port parameters:**

1. At the DTE (V.35, RS-530) port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click **<Set>**.




Figure 3-29. DTE (V.35, RS-530) Port Parameters Dialog Box

Table 3-23. DTE (V.35, RS-530) Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Enable LLB from DTE	Enables the local loop back option for the data terminal equipment Unchecked (disabled) Checked (enabled)
Enable RLB from DTE	Enables the remote loop back option for the data terminal equipment Unchecked (disabled) Checked (enabled)
[Set]	Click <Set> to set the port configuration parameters
[Cancel]	Click <Cancel> to cancel the setting of the port configuration parameters
[Refresh]	Click <Refresh> to update the data in the DTE (V.35, RS-530) Port Parameters dialog box

3.9 CONTROL Port Level – Configuration Menu

The **Configuration** menu enables you to configure at the CONTROL port level.




Figure 3-30. CONTROL Port Level Configuration Menu

Configuring the CONTROL Port Parameters

The **Parameters** command enables you to configure the CONTROL port parameters.

Note *This command is not available for the FE modem.*

➤ **To configure the CONTROL port parameters:**

1. At the CONTROL port level, select **Configuration > Parameters...**
2. Configure the desired parameters and click **<Set>**.

192.168.239.128 : 192.168.239.128 : Port Parameters

Location: Near-End

SHDSL Mode: STU-C

Port: Control

Far-End Modem Type: ASMi-52

Rate (bps): 9600

Data bits: 8

Parity: None

CTS: RTS

Interface: DCE

DCD Delay (msec): 0

DSR: DTE

Mode: Terminal

Call Out Mode: None

Dial Retries: 1

Wait For Connect (sec): 30

Dial Mode: Tone

Primary Dial No.:

Alternate No. Use: No

Alternate Dial No.:

Set Cancel Refresh

Ready

Figure 3-31. Port Parameters Dialog Box

Table 3-24. Port Parameters

Parameter	Possible Values / Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Rate (bps)	The rate of the CONTROL port (in bits per second) 9600, 19200, 38400, 57600, 115200
Data Bits	7, 8
Parity	None, Odd, Even
CTS	ON, RTS
Interface	DCE, DTE
DCD Delay (msec)	0, 10, 50, 100, 200, 300 (in milliseconds) <i>Note: This field is disabled when the Interface value is DCE</i>
DSR	ON, DTE <i>Note: This field is disabled when the Interface value is DTE</i>
Mode	Terminal, Dial Out, NMS SLIP, SMS PPP
Call Out Mode	None, All, Major
Dial Retries	0...8
Wait for Connect (sec)	30, 45, 60
Dial Mode	Tone, Pulse
Primary Dial No.	<i>Note: The maximum number of characters for this field is 20</i>
Alternate No. Use	No, Yes
Alternate Dial No.	<i>Note: The maximum number of characters for this field is 20</i>
[Set]	Click <Set> to set the port configuration parameters
[Cancel]	Click <Cancel> to close the Port Parameters dialog box
[Refresh]	Click <Refresh> to update the Port Parameters dialog box

3.10 Repeater Level – Configuration Menu

The **Configuration** menu enables you to configure at the repeater level.




Figure 3-32. Repeater Level Configuration Menu

Configuring the Repeater Parameters

The **Parameters** command enables you to configure the repeater parameters.

► **To configure the repeater parameters:**

1. At the repeater level, select **Configuration > Parameters...**
2. Configure the desired parameters and click **<Set>**.




Figure 3-33. Repeater Parameters Dialog Box{need new graphic}

Table 3-25. Repeater Parameters

Parameter	Possible Values / Remarks
Repeater	1...8
Wiring	2 Wire, 4 Wire
Loop Attenuation Threshold (dB)	Unchecked (Loop Attenuation Threshold disabled), Checked (Loop Attenuation Threshold enabled) 1...127 <i>Note: This field is read-write when the SHDSL Mode is STU-C and read-only when the SHDSL Mode is STU-R</i>
SNR Margin Threshold (dB)	Unchecked (SNR Margin Threshold disabled), Checked (SNR Margin Threshold enabled) 1...15 <i>Note: This field is read-write when the SHDSL Mode is STU-C and read-only when the SHDSL Mode is STU-R</i>
[Set]	Click <Set> to set the repeater configuration parameters
[Cancel]	Click <Close> to close the Repeater Parameters dialog box
[Refresh]	Click <Refresh> to update the Repeater Parameters dialog box

Resetting the Repeater Network Side

The **Reset Network Side** command enables you to reset the repeater network side.

► **To reset the repeater network side:**

1. In the RADview ASMi-52 window, select one of the three repeaters.
2. Select **Configuration > Reset Network Side**.

The repeater network side is reset.

3.11 Repeater Level – Diagnostics Menu

The repeater level **Diagnostics** menu allows you to test repeater diagnostics.




Figure 3-34. Repeater Level Diagnostics Menu

Testing the Repeater Diagnostics

The **Test** command enables you to test the repeater diagnostics.

► **To test the repeater diagnostics:**

- At the repeater level, select **Diagnostics > Test...**




Figure 3-35. Repeater Test Dialog Box

Table 3-26. Repeater Test Parameters

Parameter	Possible Values / Remarks
Repeater	1...8
Repeater Side	Network <i>Note: This field is read-only</i>
Current Test	None, RLB

Parameter	Possible Values / Remarks
Activate Test	<p>None, RLB Default: RLB</p> <p>Note: You cannot enter the value None while a test is currently running</p>
Test Duration (min)(0=forever)	<p>The amount of time the test will last (in minutes) 0...4095</p> <p>Note: The value 0 indicates that the test will run indefinitely</p>
[Stop]	<p>Click <Stop> to stop the test</p> <p>Note: This button is only enabled when a test is running on one of the ports</p> <p>Note: A confirmation message will appear, and the data will be updated</p>
[Apply]	<p>Click <Apply> to run the test</p> <p>Note: This button is only enabled when a test is not running on one of the ports</p> <p>Note: A confirmation message will appear, and the data will be updated</p>
[Close]	Click <Close> to close the Repeater Test dialog box
[Refresh]	Click <Refresh> to update the Repeater Test dialog box

Chapter 4

Performance Monitoring

This chapter describes the RADview options for viewing and clearing statistics information for ASMi-52. These options also include setting the Polling Interval.

4.1 System Level – Statistics Menu

The **Statistics** menu allows you to set the Polling Interval at the system level.




Figure 4-1. System Level Statistics Menu

Setting the Polling Interval

The **Polling Interval** command enables you to set the Polling Interval at the system level.

► **To set the Polling Interval at the system level:**

1. At the system level, select **Statistics > Polling Interval...**
2. Enter the desired parameter and click **<Set>**.




Figure 4-2. Polling Interval Dialog Box

Table 4-1. Polling Interval Parameters

Parameter	Possible Values/Remarks
Polling Interval (sec)	The interval at which the Agent will be polled (in seconds) 5, 10, 15...60 Default: 10 Note: The value you enter will be the interval used for both the current and running Agent statistics on all ports
[Set]	Click <Set> to set the Polling Interval
[Cancel]	Click <Cancel> to close the Polling Interval dialog box

4.2 Modem Level – Statistics Menu

The **Statistics** menu allows you to clear modem statistics at the modem level.




Figure 4-3. Modem Level Statistics Menu

Clearing Modem Statistics

The **Clear Modem Statistics** command enables you to clear statistics at the modem level.

Note *This command is unavailable for the FE modem.*

- **To clear statistics at the modem level:**
 - At the modem level, select **Statistics > Clear Modem Statistics...**

The modem statistics are cleared.

4.3 SHDSL Link Port Level – Statistics Menu

The **Statistics** menu allows you to view and clear statistics data at the SHDSL Link port level.




Figure 4-4. SHDSL Link Port Level Statistics Menu

Note *For modems with 2-wire line pairs, the word Line appears in the title bar of the dialog box. For modems with 4-wire line pairs, the word Line-A or Line-B appears in the title bar of the dialog box.*

Viewing Current 15-Minute Data for the SHDSL Link Port

The **Line > 15 min Current Data** command enables you to view port data from the beginning of the current 15-minute interval.

- **To view port data from the beginning of the current 15-minute interval:**
 - At the SHDSL Link port level, select **Statistics > Line > 15 min Current Data...**




Figure 4-5. 15 min Current Data Dialog Box

Table 4-2. 15 min Current Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Time Elapsed (sec)	The number of seconds that have elapsed since the beginning of the current 15-minute interval 0...899

Table 4-2. 15 min Current Data Parameters (Cont.)

Parameter	Possible Values/Remarks
Errored Seconds (ES)	The number of errored seconds 0...899
Severely Errored Seconds (SES)	The number of severely errored seconds 0...899
CRC Anomalies (CRCA)	The CRC (Cyclical Redundancy Checking) anomalies that have occurred since the beginning of the current 15-minute interval
Loss of Sync Word (LOSW) Seconds	The number of sync word seconds that have been lost 0...899
Unavailable Seconds (UAS)	The number of unavailable seconds 0...899
[Close]	Click < Close > to close the 15 min Current Data dialog box
[Poll]	Click < Poll > to poll the Agent

Viewing One-Day Current Data for the SHDSL Link Port

The **Line > One Day Current Data** command enables you to view port data from the beginning of the current one-day interval.

- **To view port data from the beginning of the current one-day interval:**
 - At the SHDSL Link port level, select **Statistics > Line > One Day Current Data...**




Figure 4-6. One Day Current Data Dialog Box

Table 4-3. One Day Current Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Time Elapsed (sec):	The number of seconds that have elapsed since the beginning of the current one-day interval 0...86399
Errored Seconds (ES)	The number of errored seconds 0...86399

Table 4-3 One Day Current Data Parameters (Cont.)

Parameter	Possible Values/Remarks
Severely Errored Seconds (SES)	The number of severely errored seconds 0...86399
CRC Anomalies (CRCA)	The CRC (Cyclical Redundancy Checking) anomalies that have occurred since the beginning of the current one-day interval
Loss of Sync Word (LOSWS) Seconds	The number of sync word seconds that have been lost 0...86399
Unavailable Seconds (UAS)	The number of unavailable seconds 0...86399
[Close]	Click <Close> to close the One Day Current Data dialog box
[Poll]	Click <Poll> to poll the Agent

Viewing 15-Minute Interval Data for the SHDSL Link Port

The **Line > 15 min Interval Data** command enables you to view port data for all 15-minute intervals over the last 24 hours.

- **To view port data for all 15-minute intervals over the last 24 hours:**
 - At the SHDSL Link port level, select **Statistics > Line > 15 min Interval Data...**




Figure 4-7. 15 min Interval Data Dialog Box

Table 4-4. 15 min Interval Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Inv. No.	The interval number 1...96
From (hh:mm)	The time the interval began, in the format hh:mm
To (hh:mm)	The time the interval ended, in the format hh:mm
ES	The number of errored seconds 0...899

Table 4-4. 15 min Interval Data Parameters (Cont.)

Parameter	Possible Values/Remarks
SES	The number of severely errored seconds 0...899
CRC Anomalies	The CRC (Cyclical Redundancy Checking) anomalies that have occurred since the beginning of the last 24-hour period
LOSWS	The number of sync word seconds that have been lost 0...899
UAS	The number of unavailable seconds 0...899
[Close]	Click <Close> to close the 15 min Interval Data dialog box

Viewing One-Day Interval Data for the SHDSL Link Port

The **Line > One Day Interval Data** command enables you to view SHDSL Link port data at one-day intervals.

- **To view port data at one-day intervals:**
 - At the SHDSL Link port level, select **Statistics > Line > One Day Interval Data...**




Figure 4-8. One Day Interval Data Dialog Box

Table 4-5. One Day Interval Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Days Ago	The number of daily intervals for which data is displayed 1...7 Note: The field is empty when no table entries exist
ES	The number of errored seconds
SES	The number of severely errored seconds
CRC Anomalies	The CRC (Cyclical Redundancy Checking) anomalies that have occurred since the beginning of the last 24-hour period

Table 4-5. One Day Interval Data Parameters (Cont.)

Parameter	Possible Values/Remarks
LOSW	The number of sync word seconds that have been lost
UAS	The number of unavailable seconds
[Close]	Click <Close> to close the One Day Interval Data dialog box

Viewing Accumulated Data for the SHDSL Link Port

The **Line > Accumulated Data** command enables you to view accumulated port data.

➤ **To view accumulated port data:**

- At the SHDSL Link port level, select **Statistics > Line > Accumulated Data...**




Figure 4-9. Accumulated Data Dialog Box

Table 4-6. Accumulated Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Errored Seconds (ES)	The number of errored seconds
Severely Errored Seconds (SES)	The number of severely errored seconds
CRC Anomalies (CRCA)	The CRC (Cyclical Redundancy Checking) anomalies that have accumulated
Loss of Sync Word (LOSW) Seconds	The number of sync word seconds that have been lost
Unavailable Seconds (UAS)	The number of unavailable seconds
[Close]	Click <Close> to close the Accumulated Data dialog box
[Poll]	Click <Poll> to poll the Agent

Clearing Statistics for the SHDSL Link Port

The **Statistics > Clear Statistics** command enables you to clear port statistics at the SHDSL Link port level.

- **To clear port statistics at the SHDSL Link port level:**
 - At the SHDSL Link port level, select **Statistics > Clear Statistics...**

The statistics for the SHDSL Link port are cleared.

4.4 E1/T1 Port Level – Statistics Menu

The **Statistics** menu allows you view and clear statistics data at the E1/T1 port level.




Figure 4-10. E1/T1 Port Level Statistics Menu

Viewing BPV Statistics

The **BPV** command enables you to view BPV data.

Note This command is available for the E1 port when the line type is E1-MF (G732S) or Unframed, or for the T1 port when the line type is D4 (SF) or Unframed.

► **To view BPV data:**

- At the E1/T1 port level, select **Statistics > BPV...**




Figure 4-11. BPV Statistics Dialog Box

Table 4-7. BPV Statistics Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
BPV Last Minute	0...1000

Table 4-7. BPV Statistics Parameters (Cont.)

Parameter	Possible Values/Remarks
BPV Worst Minute	0...1000
[Close]	Click <Close> to close the BPV Statistics dialog box
[Poll]	Click <Poll> to poll the Agent

Viewing Current 15-Minute Port Data

The **15 min Current Data** command enables you to view port data from the beginning of the current 15-minute interval.

Note *This command is available for the E1 port when the line type is E1-CRC (G732N-CRC), or for the T1 port when the line type is ESF.*

- **To view port data from the beginning of the current 15-minute interval:**
 - At the E1/T1 port level, select **Statistics > 15 min Current Data...**




Figure 4-12. 15 min Current Data Dialog Box

Table 4-8. 15 min Current Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Time Elapsed (sec)	The number of seconds that have elapsed since the beginning of the current 15-minute interval 0...899

Table 4-8. 15 min Current Data Parameters (Cont.)

Parameter	Possible Values/Remarks
Errored Seconds (ES)	The number of errored seconds 0...899
Unavailable Seconds (UAS)	The number of seconds that are unavailable 0...899
Severely Errored Seconds (SES)	The number of severely errored seconds 0...899
Bursty Errored Seconds (BES)	The number of bursty errored seconds 0...899
Loss of Frame (LOFC)	Description of frame loss
Controlled Slip Seconds (CSS)	The number of controlled slip seconds 0...899
Degraded Minutes (DM)	The number of degraded minutes 0...15
CRC Error Event	Description of CRC error event
CRC Average Error Event	Description of CRC average error event
[Close]	Click <Close> to close the 15 min Current Data dialog box
[Poll]	Click <Poll> to poll the Agent

Viewing 15-Minute Interval Port Data

The **15 min Interval Data** command enables you to view port data for all 15-minute intervals over the last 24 hours.

Note *This command is available for the E1 port when the line type is E1-CRC (G732N-CRC), or for the T1 port when the line type is ESF.*

- **To view port data for all 15-minute intervals over the last 24 hours:**
 - At the E1/T1 port level, select **Statistics > 15 min Interval Data...**




Figure 4-13. 15 min Interval Data Dialog Box

Table 4-9. Interval Data Parameters

Parameter	Possible Values/Remarks
Location	Near-End, Far-End
SHDSL Mode	STU-C, STU-R
Port	CONTROL, ETH, SHDSL Link, E1, T1, DTE (V.35, X.21, RS-530)
Far-End Modem Type	Unknown, ASMi-52, ASMi-52 Master, ASMi-52 Slave, ASMi-52/CD, ASMi-52/CQ, LRS-52, FCD-IP, FCD-IPM, D8SL, MP-SHDSL
Valid Intervals	The total number of valid intervals since the beginning of the last 24-hour period 0...96

Table 4-9 Interval Data Parameters (Cont.)

Parameter	Possible Values/Remarks
Inv. No.	The interval number 1...96
From	The time the interval began, format hh:mm
To	The time the interval ended, format hh:mm
ES	The number of errored seconds
UAS	The number of unavailable seconds
SES	The number of severely errored seconds
BES	The number of bursty errored seconds 0...899
LOFC	Description of frame loss
CSS	The number of controlled slip seconds 0...899
DM	The number of degraded minutes 0...15
[Close]	Click <Close> to close the Interval Data dialog box
[Poll]	Click <Poll> to poll the Agent

Clearing Statistics for the E1/T1 Port

The **Clear Statistics** command enables you to clear statistics for the E1/T1 port.

➤ **To clear statistics for the E1/T1 port:**

- At the E1/T1 port level, select **Statistics > Clear Statistics...**

The statistics for the E1/T1 port are cleared.

Appendix A

Active Alarms

This appendix lists the active alarms for ASMi-52 fault management at the modem, port, and repeater levels.

A.1 Modem Level – Active Alarms

At the modem level, active alarms may be displayed at the modem and port levels combined, or at the modem level alone.

Modem and Port Levels

Table A-1 lists the active alarms at the modem and port levels combined.

Table A-1. Modem Level Active Alarms: Modem and Port Levels Combined

Code	Severity	Description
1	Major	SELF TEST ERROR Failure occurred while testing the port hardware components
2	Warning	SOFTWARE DOWNLOAD Port currently performing software download
3	Warning	INBAND LOOP Inband-activated loopback in progress
4	Warning	LLB FROM DTE Local loopback activated by physical connector <i>Note: This alarm will only appear if the V.35 or RS-530 interface is present</i>
5	Warning	RLB FROM DTE Remote loopback activated by physical connector <i>Note: This alarm will only appear if the V.35 or RS-530 interface is present</i>
6	Major	PROP PROT FAIL RAD proprietary protocol between devices failed
7	Major	E1 TS NUM NOT COMP LRSi card not supported in this device
8	Major	LAN NOT CONNECTED LAN not connected (for Ethernet interfaces)
9	Minor	LOOP ATTN. OVER LINE A Loop attenuation exceeded alarm threshold at line A
10	Minor	LOOP ATTN. OVER LINE B Loop attenuation exceeded alarm threshold at line B

Table A-1. Modem Level Active Alarms: Modem and Port Levels Combined (Cont.)

Code	Severity	Description
11	Minor	SNR MARGIN OVER LINE A SNR margin exceeded alarm threshold at line A
12	Minor	SNR MARGIN OVER LINE B SNR margin exceeded alarm threshold at line B
13	Minor	LOSW FAILURE OVER LINE A Forward LOSW alarm occurred at line A
14	Minor	LOSW FAILURE OVER LINE B Forward LOSW alarm occurred at line B
15	Major	DATA RATE NOT COMPATIBLE Data rate and line rate are not compatible <i>Note: This alarm will only appear if the V.35 interface is present</i>
16	Minor	PSD NOT COMPATIBLE PSD mode set by user is not compatible with the PSD mode in use
17	Major	SYNC LOSS LINE A G.SHDSL line A not synchronized
18	Major	SYNC LOSS LINE B G.SHDSL line B not synchronized <i>Note: This alarm will only appear if the modem is 4 wire</i>
19	Major	MNGMNT IS DOWN Management between NE and FE is down (EOC problem)
20	Major	ILLEGAL EXTER CLK External clock not compatible to clock set by user for DTE (not supported in this device)
21	Minor	CRC ERROR OVER LINE A Too many CRC errors received on G.SHDSL at line A
22	Minor	CRC ERROR OVER LINE B Too many CRC errors received on G.SHDSL at line B
23	Major	NO DTE INTERFACE Device lacks a DTE interface
24	Major	INTERFACE RATE FAIL Line rate failed to meet one of the following conditions: — When interface is G704 or G703, line rate may be up to 2048 Kbps, or one unit up to 2 Mbps and the other unit up to 4 Mbps — When remote unit is G703, line rate is not 2048 Kbps
25	Major	E1 REMOTE FAILURE E1 on FE received red alarm
26	Major	E1-TS NOT RATE COMP Number of connected time slots in E1 line not equal to line rate
27	Major	E1 SIGNAL LOSS E1 loss of receiving signal occurred

Table A-1. Modem Level Active Alarms: Modem and Port Levels Combined (Cont.)

Code	Severity	Description
28	Minor	E1 BPV ERR EXC Bipolar violation error exceeded threshold
29	Minor	E1 FRAME SLIP EXC Detected E1 frame slips exceeded threshold
30	Major	E1 EXCESSIVE BPV Rate of bipolar violations exceeded 1×10^{-6} for period of 1000 seconds
31	Minor	E1 CRC-4 EXC Detected CRC-4 errors exceeded threshold
32	Major	E1 EXCESSIVE ERR RATIO Bit error link rate exceeded 10^{-3}
33	Major	E1 AIS OCCURRED AIS detected on E1
34	Major	E1 AIS AND SYNC LOSS AIS and loss of frame alignment occurred on E1
35	Major	E1 SYNC LOSS Loss of frame synchronization occurred on E1
36	Minor	E1 CRC MF EXC Detected CRC errors in LRS52 frame synchronization signal exceeded threshold
37	Major	E1 REMOTE SYNC LOSS Remote loss of frame synchronization occurred
38	Major	E1 MF SYNC LOSS Local loss of LRS52 frame synchronization occurred
39	Major	E1 MF REMOTE SYNC LOSS Remote loss of LRS52 frame synchronization occurred
40	Major	E1 TS NUM NOT X128 For 4 Wire modem, user set time slot with number that is not a multiple of X 128 <i>Note: This alarm will only appear when both E1 and V.35 interfaces are present (or any other interface which is not G704)</i>
41	Major	E1 TS NUM NOT COMP Number of time slots in NE and FE do not correspond
42	Major	WIRE MODE NOT COMP Line interface types (2 wire and 4 wire) for local and remote units do not correspond
43	Major	SPAN IS NOT FULL Span containing information on central office, customer premises equipment, and repeaters is experiencing a problem on one of its segments
50	Major	LINE PARAMETERS NOT COMP Configuration parameters do not correspond, causing a lack of synchronization between NE and FE

Table A-1. Modem Level Active Alarms: Modem and Port Levels Combined (Cont.)

Code	Severity	Description
51	Major	EXTERNAL TO INTERNAL CLOCK Clock missing at the external clock source
60	Major	SELF TEST ERROR Failure occurred while testing the device hardware components
61	Warning	SOFTWARE DOWNLOAD Device currently performing software download
62	Major	PS1 Fail Failure occurred in PS 1
63	Major	PS2 Fail Failure occurred in PS 2
64	Major	FAN1 FAIL Failure occurred in FAN 1
65	Major	FAN2 FAIL Failure in FAN 2 occurred
66	Major	OVER TEMPERATURE Device temperature exceeded maximum range

Modem Level

Table A-2 lists the active alarms at the modem level only.

Table A-2. Modem Level Active Alarms: Modem Level

Code	Severity	Description
1	Major	SELF TEST ERROR Failure occurred while testing the port hardware components
2	Warning	SOFTWARE DOWNLOAD Port currently performing software download
20	Major	ILLEGAL EXTER CLK External clock not compatible to clock set by user for DTE (not supported in this device)
23	Major	NO DTE INTERFACE Device lacks a DTE interface
42	Major	WIRE MODE NOT COMP Line interface types (2 wire and 4 wire) for local and remote units do not correspond
43	Major	SPAN IS NOT FULL Span containing information on central office, customer premises equipment, and repeaters is experiencing a problem on one of its segments
51	Major	EXTERNAL TO INTERNAL CLOCK Clock missing at the external clock source
60	Major	SELF TEST ERROR Failure occurred while testing the device hardware components

Table A-2. Modem Level Active Alarms: Modem Level (Cont.)

Code	Severity	Description
61	Warning	SOFTWARE DOWNLOAD Device currently performing software download
62	Major	PS1 Fail Failure occurred in PS 1
63	Major	PS2 Fail Failure occurred in PS 2
64	Major	FAN1 FAIL Failure occurred in FAN 1
65	Major	FAN2 FAIL Failure occurred in FAN 2
66	Major	OVER TEMPERATURE Device temperature exceeded maximum range

A.2 SHDSL Link Port Level – Active Alarms

Active alarms may be displayed at the SHDSL Link port level.

[Table A-3](#) lists the active alarms at the SHDSL Link port level.

Table A-3. SHDSL Link Port Level Active Alarms

Code	Severity	Description
3	Warning	INBAND LOOP Inband-activated loopback in progress
6	Major	PROP PROT FAIL RAD proprietary protocol between devices failed
9	Minor	LOOP ATTN. OVER LINE A Loop attenuation exceeded alarm threshold at line A
10	Minor	LOOP ATTN. OVER LINE B Loop attenuation exceeded alarm threshold at line B
11	Minor	SNR MARGIN OVER LINE A SNR margin exceeded alarm threshold at line A
12	Minor	SNR MARGIN OVER LINE B SNR margin exceeded alarm threshold at line B
13	Minor	LOSW FAILURE OVER LINE A Forward LOSW alarm occurred at line A
14	Minor	LOSW FAILURE OVER LINE B Forward LOSW alarm occurred at line B
16	Minor	PSD NOT COMPATIBLE PSD mode set by user not compatible with PSD mode in use

Table A-3. SHDSL Link Port Level Active Alarms (Cont.)

Code	Severity	Description
17	Major	SYNC LOSS LINE A G.SHDSL line A not synchronized
18	Major	SYNC LOSS LINE B G.SHDSL line B not synchronized <i>Note: This alarm will only appear if the modem is 4 wire</i>
19	Major	MNGMNT IS DOWN Management between NE and FE down (EOC problem)
21	Major	ILLEGAL EXTER CLK External clock not compatible to clock set by user for DTE (not supported in this device)
22	Minor	CRC ERROR OVER LINE A Too many CRC errors received on G.SHDSL at line A
50	Major	LINE PARAMETERS NOT COMP Configuration parameters do not correspond, causing a lack of synchronization between NE and FE

A.3 ETH Port Level – Active Alarms

One active alarm may be displayed at the ETH port level.

[Table A-4](#) lists the active alarm at the ETH port level.

Table A-4. ETH Port Level Active Alarm

Code	Severity	Description
8	Major	LAN NOT CONNECTED LAN not connected (for Ethernet interfaces)

A.4 E1/T1 Port Level – Active Alarms

Active alarms may be displayed at the E1/T1 port level.

[Table A-5](#) lists the active alarms at the E1/T1 port level.

Table A-5. E1/T1 Port Level Active Alarms

Code	Severity	Description
7	Major	E1 TS NUM NOT COMP LRSi card not supported in this device
24	Major	INTERFACE RATE FAIL Line rate failed to meet one of the following conditions: — When interface is G704 or G703, line rate may be up to 2048 Kbps, or one unit up to 2 Mbps and the other unit up to 4 Mbps — When remote unit is G703, line rate is not 2048 Kbps
25	Major	E1 REMOTE FAILURE E1 on FE received red alarm
26	Major	E1-TS NOT RATE COMP Number of connected time slots in E1 line not equal to line rate
27	Major	E1 SIGNAL LOSS E1 loss of receiving signal occurred
28	Minor	E1 BPV ERR EXC Bipolar violation error exceeded threshold
29	Minor	E1 FRAME SLIP EXC Detected E1 frame slips exceeded threshold
30	Major	E1 EXCESSIVE BPV Rate of bipolar violations exceeded 1×10^{-6} for period of 1000 seconds
31	Minor	E1 CRC-4 EXC Detected CRC-4 errors exceeded threshold
32	Major	E1 EXCESSIVE ERR RATIO Bit error link rate exceeded 10^{-3}
33	Major	E1 AIS OCCURRED AIS detected on E1
34	Major	E1 AIS AND SYNC LOSS AIS and loss of frame alignment occurred on E1
35	Major	E1 SYNC LOSS Loss of frame synchronization occurred on E1
36	Minor	E1 CRC MF EXC Detected CRC errors in LRS52 frame synchronization signal exceeded threshold
37	Major	E1 REMOTE SYNC LOSS Remote loss of frame synchronization occurred

Table A-5. E1/T1 Port Level Active Alarms (Cont.)

Code	Severity	Description
38	Major	E1 MF SYNC LOSS Local loss of LRS52 frame synchronization occurred
39	Major	E1 MF REMOTE SYNC LOSS Remote loss of LRS52 frame synchronization occurred
40	Major	E1 TS NUM NOT X128 For 4 Wire modem, user set time slot with number that is not a multiple of X 128 <i>Note: This alarm will only appear when both E1 and V.35 interfaces are present (or any other interface which is not G704)</i>
41	Major	E1 TS NUM NOT COMP Number of time slots in NE and FE do not correspond

A.5 DTE (V.35, X.21, RS-530) Port Levels – Active Alarms

Active alarms may be displayed at the DTE (V.35, X.21, RS-530) port levels.

[Table A-6](#) lists the active alarms at the DTE (V.35, X.21, RS-530) port levels.

Table A-6. DTE (V.35, X.21, RS-530) Port Level Active Alarms

Code	Severity	Description
1	Major	SELF TEST ERROR Failure occurred while testing the port hardware components
4	Warning	LLB FROM DTE Local loopback activated by physical connector <i>Note: This alarm will only appear if the V.35 or RS-530 interface is present</i>
5	Warning	RLB FROM DTE Remote loopback activated by physical connector <i>Note: This alarm will only appear if the V.35 or interface is present</i>
51	Major	EXTERNAL TO INTERNAL CLOCK Clock missing at the external clock source

A.6 Repeater Level – Active Alarms

Active alarms may be displayed at the repeater level.

[Table A-7](#) lists/describes the active alarms at repeater level.

Table A-7. Repeater Level Active Alarms

Code	Severity	Description
44	Major	Network side loop attenuation alarm occurred
45	Major	Customer side loop attenuation alarm occurred
46	Major	Network side SNR margin alarm occurred
47	Major	Customer side SNR margin alarm occurred
48	Major	Network side SHDSL LOSW failure alarm occurred
49	Major	Customer side SHDSL LOSW failure alarm occurred

Index

—A—

Active alarms

- DTE port, 2-11
- E1 and T1 port, 2-9
- ETH port, 2-8
- modem, 2-2, 2-3
- port, 2-2
- repeater, 2-12
- SHDSL link port, 2-6
- system, 2-1

Agent, polling, 3-2

Alarms

- active DTE port, 2-11
- active E1 and T1 port, 2-9
- active ETH port, 2-8
- active modem, 2-2, 2-3
- active port, 2-2
- active repeater, 2-12
- active SHDSL link port, 2-6
- active system, 2-1
- clearing buffer, 2-1
- clearing history log, 2-1

ASMi-52 introduction, 1-1

—B—

Bandwidth,viewing, 3-8

BERT,testing, 3-20

BPV statistics, viewing, 4-12

Bridging table

- adding static entry, 3-16
- configuring, 3-14

Buffer, alarms, 2-1

—C—

Clearing

- alarm buffer, 2-1
- E1 and T1 port level statistics, 4-17
- history log, 2-1
- modem statistics, 4-2
- SHDSL link port level statistics, 4-11

Configuration

- resetting, 3-18

Configuration management

- overview, 3-1
- system level, 3-1

Configuration menu

- CONTROL port level, 3-31

DTE port level, 3-30

E1 and T1 port level, 3-26

Ethernet port level, 3-25

modem level, 3-6

repeater level, 3-33

SHDSL link port level, 3-21

Configuring

- bridging table, 3-14
- CONTROL port level parameters, 3-32
- DTE port level parameters, 3-30
- E1 port level parameters, 3-26
- ETH port level parameters, 3-25
- LAN, 3-13
- manager list, 3-5
- modem parameters, 3-7
- QoS Mapping, 3-17
- repeater level parameters, 3-34
- SHDSL link port level parameters, 3-21
- system information, 3-1
- T1 port level parameters, 3-29

CONTROL port

- configuration menu, 3-31
- configuring parameters, 3-32
- operations, 1-11

—D—

Defining

- system information, 3-1
- time slot assignment, 3-10
- time slot group, 3-12

Device

- management options, 1-5
- overview, 1-1

Diagnostics menu

- modem level, 3-18
- repeater level, 3-35

Displaying active alarms

- DTE port, 2-11
- E1 and T1 port, 2-9
- ETH port, 2-8
- modem, 2-2, 2-3
- port, 2-2
- repeater, 2-12
- SHDSL link port, 2-6
- system, 2-1

Displaying history log

- modem active alarms, 2-5
- repeater alarms, 2-14

Displaying NE and FE modems, 1-2

DTE port

- configuration menu, 3-30
- configuring parameters, 3-30
- displaying active alarms, 2-11
- fault management, 2-11
- operations, 1-10

—E—**E1 and T1 port**

- clearing statistics, 4-17
- configuration menu, 3-26
- displaying active alarms, 2-9
- fault management, 2-9
- operations, 1-9
- statistics menu, 4-11
- viewing 15 minute interval data, 4-15
- viewing current 15 minute data, 4-13

E1 port, configuring parameters, 3-26**ETH port**

- configuring parameters, 3-25
- displaying active alarms, 2-8
- fault management, 2-8
- operations, 1-9

Ethernet port

- configuration menu, 3-25

—F—**Fault management**

- DTE port level, 2-11
- E1 and T1 port level, 2-9
- ETH port level, 2-8
- modem level, 2-2
- overview, 2-1, A-1
- port level, 2-2, A-5, A-6, A-7, A-8, A-9
- repeater level, 2-12
- SHDSL link port level, 2-6
- system level, 2-1

FCAPS overview, 1-1**—G—****Graphical user interface, 1-2****—H—****History log**

- clearing alarms, 2-1
- displaying modem active alarms, 2-5
- displaying repeater alarms, 2-14

Host interface list, viewing, 3-3**Host interface, configuring, 3-3****—I—****Introduction, 1-1****—L—****LAN, configuring, 3-13****LEDs, 1-3****Line, resetting configuration, 3-18****—M—****Manager list, configuring, 3-5****Managing**

- configuration, 3-1
- faults, 2-1, A-1

Menu bar, 1-3**Modem**

- clearing statistics, 4-2
- configuration menu, 3-6
- configuring parameters, 3-7
- diagnostics menu, 3-18
- displaying active alarms, 2-2, 2-3
- displaying history log, 2-5
- displaying NE and FE devices, 1-2
- fault management, 2-2
- operations, 1-6
- resetting configuration, 3-18
- resetting hardware, 3-18
- statistics menu, 4-2
- testing diagnostics, 3-18
- viewing, 3-6

—O—**Operations**

- CONTROL port level, 1-11
- DTE port level, 1-10
- E1 and T1 port level, 1-9
- ETH port level, 1-9
- modem level, 1-6
- repeater level, 1-11
- SHDSL link port level, 1-8
- system level, 1-5

Options menu, system level, 3-2**Overview**

- ASMi-52 Device, 1-1
- configuration management, 3-1
- performance monitoring, 4-1
- RADview FCAPS model, 1-1

—P—**Performance monitoring overview, 4-1****Polling**

- agent, 3-2
- setting, 3-6
- setting interval, 4-1

Port

- displaying active alarms, 2-2
- fault management, 2-2
- viewing status, 1-5

Port level

- fault management, A-5, A-6, A-7, A-8, A-9

—Q—**QoS mapping, configuring, 3-17****—R—****Repeater**

- configuration menu, 3-33

- configuring parameters, 3-34
 - diagnostics menu, 3-35
 - diagnostics testing, 3-35
 - displaying active alarms, 2-12
 - displaying history log, 2-14
 - fault management, 2-12
 - operations, 1-11
 - resetting network side, 3-35
- Resetting
- configuration, 3-18
 - line configuration, 3-18
 - modem configuration, 3-18
 - modem hardware, 3-18
 - repeater network side, 3-35
- S—
- Selecting objects in window, 1-2
- Setting
- polling, 3-6
 - polling interval, 4-1
 - system information, 3-1
- SHDSL link port
- clearing statistics, 4-11
 - configuration menu, 3-21
 - configuring parameters, 3-21
 - displaying active alarms, 2-6
 - fault management, 2-6
 - operations, 1-8
 - statistics menu, 4-2
 - viewing 15 minute interval data, 4-6
 - viewing accumulated data, 4-10
 - viewing configuration, 3-23
 - viewing current 15 minute data, 4-2
 - viewing one day current data, 4-4
 - viewing one day interval data, 4-8
- Statistics menu
- E1 and T1 port level, 4-11
 - modem level, 4-2
 - SHDSL link port level, 4-2
- Status bar, 1-3
- System information
- setting, 3-1
 - viewing, 3-1
- System level
- configuration management, 3-1
 - displaying active alarms, 2-1
 - fault management, 2-1
 - management, 1-5
 - operations, 1-5
 - options menu, 3-2
- T—
- T1 port, configuring parameters, 3-29
- Testing
- BERT, 3-20
 - modem diagnostics, 3-18
 - repeater diagnostics, 3-35
- Time slot group, defining, 3-12
- Toolbar, 1-3
- U—
- Using
- graphical user interface, 1-2
 - menu bar, 1-3
 - status bar, 1-3
 - toolbar, 1-3
- V—
- Viewing
- Bandwidth, 3-8
 - BVP statistics, 4-12
 - E1 and T1 port level 15 minute interval data, 4-15
 - E1 and T1 port level current 15 minute data, 4-13
 - host interface list, 3-3
 - LEDs, 1-3
 - modem, 3-6
 - port status, 1-5
 - SHDSL link port level 15 minute interval data, 4-6
 - SHDSL link port level accumulated data, 4-10
 - SHDSL link port level configuration, 3-23
 - SHDSL link port level current 15 minute data, 4-2
 - SHDSL link port level one day current data, 4-4
 - SHDSL link port level one day interval data, 4-8
 - system information, 3-1
- W—
- Window, selecting objects in, 1-2

